

# MOVING TERRAIN®

# MT-VisionAir X



**User Manual Version X.6.x**

The compilation of texts and pictures was made with the utmost care. Nevertheless, errors can not be completely excluded. Editor and authors can not take on responsibility for incorrect information and the consequences thereof neither legal responsibility nor liability of any kind. The publisher is grateful for information on any error.

\*\*\*

### **WARRANTY AND LIABILITY ADVICE**

This software is to facilitate your terrestrial navigation only. It is not a certified aviation equipment and does not replace any aircraft instrument. You are explicitly cautioned to verify that the hardware employed is functioning correctly and does not interfere with the aircraft or other vessel in a hazardous manner. Data errors and computer errors are possible. This also pertains to the IFR data and procedures implied in the respective modules. Human error can make the moving map, nav data or any supplemental information incorrect. The pilot in command remains the final authority on the accuracy and sufficiency of the hardware and software.

#### **Warranty and Liability Disclaimer:**

The manufacturer, distributor or sales agent resume no liability as to the correct function of the software, the availability of a reference signal (GPS) or the validity of the charts, nav data or any supplemental information like airport information and others. Never will the manufacturer, producer, sales representative and neither of their staff be liable to you for any consequential incidental or indirect damages (including damages for loss of business profits, business interruption, loss of business information and the like) arising from the use of or inability to use the software even if any of the staff mentioned above has been advised.

There is no warranty, express or implied, including without limitation the implied warranties of merchantability and fitness for a particular purpose, regarding the software. The entire risk as to the results and performance of the hardware and software is assumed by you.

\*\*\*

Moving Terrain is a registered trademark of:

Moving Terrain AG  
 Air Navigation Systems  
 Sparenberg 1  
 87477 Sulzberg  
 Germany

Tel: +49 8376 9214-0

Fax: +49 8376 9214-14

Revisions:

Date	Changes / Additions / Corrections	Revision	Valid Pages
15/02/22	1st edition	MTEX/IA-05-00	82
15/11/23	2nd edition	MTEX/IA-05-01	124
15/11/26	3 <sup>rd</sup> edition	MTEX/IA-05-02	124
16/02/16	4 <sup>th</sup> edition	MTEX/IA-05-03	137
16/05/20	5 <sup>th</sup> edition: Version X.6.x MT Obstacles / Street databases	MTEX/IA-05-04	159
17/02/14	6 <sup>th</sup> edition: Version X.6.x New screen layout	MTEX/IA-05-05	158

# Contents

<b>1. MT Basic.....</b>	<b>11</b>
1.1. Power on MT VisionAir X and confirm the disclaimer with AGREE.....	11
1.2. Positioning via GPS / related info in the Info Box.....	11
1.3. Dimming the screen .....	11
1.4. Restart of MT VisionAir X (wait stead).....	12
1.5. Keyboard.....	13
1.5.1. Hot Keys - Flight Mode.....	13
1.5.2. Hot Keys – Map Mode.....	14
1.5.3. Positioning of chart using the arrow keys.....	14
1.6. Simulator mode.....	15
1.6.1. Switch on the simulator.....	15
1.6.2. Switch off the simulator mode.....	15
1.6.3. Adjust the parameter in simulated flight.....	15
1.7. Symbols on the screen.....	16
1.7.1. Overview: Synchronized 2D / 3D.....	16
1.7.2. On the chart.....	17
1.7.3. Full Screen Terrain (Relief Dynamics).....	18
1.7.4. EFIS Horizon (→ EFIS → HORIZ).....	20
1.7.5. Split Screen MT Terrain EFIS with Moving Map.....	21
1.7.6. Split Screen MT EFIS with Moving Map.....	22
1.8. Function keys – general info.....	22
1.9. Symbols – general Info (Symbols on the Moving Map).....	23
1.9.1. No Positioning from GPS.....	23
1.9.2. Position Symbols.....	23
1.9.3. Obstacles.....	24
1.9.4. Linear / Frame Symbols .....	24
<b>2. DIRECT / GO TO / NEAREST/ Defined Waypoints DEF.....</b>	<b>25</b>
2.1. Direct.....	25
2.1.1. Direct from NAV Waypoint Page.....	25
2.1.2. Continuous DCT Update = Hotkey T.....	28
2.1.3. Temporarily Direct = DCTtmp.....	28
2.1.4. Direct to Waypoint in Routes.....	28
2.2. GOTO.....	28
2.3. Nearest Airports.....	29
2.3.1. Hot Key N shows the 3 Nearest Airports.....	29
2.3.2. NEAREST Airport in 2D = Information and Symbols.....	30
2.3.3. NEAREST in 3D = virtual ILS to the runway.....	30
2.3.4. Possibilities to display NEAREST.....	31
2.3.2. Delete NEAREST.....	32
2.4. Defined Waypoints REF using Radial / DME.....	33

2.4.1. Pre-Settings for REF.....	33
2.4.2. Define the RADIAL DME Waypoint.....	34
2.4.3. Work with RADIAL DME Waypoints.....	36
2.4.4. RADIAL DME Defined Waypoint based on a User Waypoint.....	37
<b>3. Special Coordinates * .....</b>	<b>39</b>
3.1. UTM.....	40
3.1. Swiss Grid.....	41
<b>4. MT-Obstacles * .....</b>	<b>42</b>
4.1. Coverage / Disclaimer and Updates.....	42
4.2. Displaying the obstacles: on / off.....	42
4.3. Representation of single or point obstacles.....	42
4.3.1. 2D representation.....	42
4.3.2. 3D view.....	43
4.3.3. Table of individual obstacles (single or point obstacles).....	43
4.4. Representation of cables and cables (linear obstacles).....	46
4.4.1. 2D Representation.....	46
4.4.2. 3D Representation.....	46
4.4.3. Table of linear obstacle.....	47
<b>5. CHARTS.....</b>	<b>51</b>
5.1. Base Charts.....	51
5.1.1. Automatic switch to the next chart by using ZOOM.....	51
5.1.2. Order of the Charts.....	52
5.1.3. Base Chart Selection.....	53
5.2. Single Chart Selection (Approach Plates are typical Single Charts).....	54
5.2.1. VFR Approach Charts (JeppView).....	54
5.2.2. VFR Approach Plates of Deutsche Flugsicherung (German Flight Safety).....	56
5.2.3. Overview, Europe overview chart, USA overview chart.....	57
5.2.4. Automatic Pre-selection of Single Charts.....	58
<b>6. VIEW – Adjustment of the Display.....</b>	<b>59</b>
6.1. → ZOOM (see chapter 3.1. Base Charts).....	59
6.2. Aircraft Symbol Center or Off Center .....	59
6.3. Chart Track Up or North Up.....	59
6.4. → MFD.....	59
6.4.1. Why do we need the MFD mode?.....	60
<b>7. NAV Waypoint Page → navWPT.....</b>	<b>61</b>
7.1. Standard data bases.....	61
7.1.1. Hints for waypoint search.....	62
7.1.2. Mistype?.....	62
7.1.3. Switch to other waypoint data bases.....	62
7.1.4. Direct (q.v. 2.1.).....	63

7.1.5. Delete Direct .....	63
7.2. User Waypoints (use → EDIT).....	63
7.2.1. To enter a new waypoint → NEW.....	63
7.2.2. Modify an existing waypoints → MODIFY.....	63
7.2.3. Delete a waypoint which is no longer needed → ERASE.....	63
7.2.4. REF Waypoint defined by Radial DME (see 2.4).....	63
7.3. Further Waypoint databases.....	64
7.3.1. VFR reporting points.....	64
7.3.2. Streetdata.....	64
<b>8. NAV Route → navRTE.....</b>	<b>67</b>
8.1. Compilation of a route.....	67
8.2. Switch to another data base.....	68
8.3. Insert of current position in the flightplan.....	68
8.4. Save, Load, Modify and Delete → ROUTES.....	69
8.5. → AUXrte – further functions for planning a route.....	69
<b>9. Further Functions → AUX.....</b>	<b>70</b>
9.1. → TRACK: Track Saving and Automated Logbook.....	70
9.1.1. Track recording → AUX → TRACK.....	70
9.1.2. Logbook → AUX → TRACK.....	70
9.2. → SETUP: Adjustment / Indication of Configuration Parameters.....	70
9.2.1. Software version.....	70
9.2.2. Switch to metric measurement units.....	70
9.2.3. Date of the Obstacle Data.....	71
9.2.4. Hiding of Info to Clear up the Screen (i.e. Delete of the DIRECT).....	71
9.2.5. GPS Selection.....	71
9.2.6. Selection of Phone / Download.....	71
9.2.7. Switch between Jet or Heli Symbol .....	72
9.3. → AUX→ SYS → BACKUP / Restore or Transfer of User Data.....	73
9.4. → AUX→ RESET.....	73
<b>10. Flightplan / Route Transmission *.....</b>	<b>74</b>
10.1. Transmission of a Flight plan from Garmin 430 (XFILL- Option).....	74
10.2. Transmission and Displaying of a User Route from an External Flightplanning Program.....	74
10.2.1. Work with external Flightplanning Program.....	74
10.2.2. Transmission to MT-VisionAir X.....	74
10.2.3. Load the Route.....	75
10.2.4. Display of the Route in the NAV RTE Page and on the Chart.....	75
10.2.5. Error Messages using IMPORT Function.....	76
10.2.6. Example of GPX file recognized by the VisionAir X.....	77
<b>11. MT-IFR Complete Package *.....</b>	<b>78</b>

11.1. MT-ENROUTE Layer *	78
11.1.1. MT-Enroute Layer without chart (MFD mode)	78
11.1.2. MT-Enroute Layer over the ICAO charts	79
11.2. Electronic Flight Bag	79
11.2.1. Selection / Alteration of an active airport	80
11.2.2. Selection of a Category SID STAR APPROACH APT OTHERS	80
11.2.3. Selection and Displaying of a SID or STAR or Information	80
11.2.4. Selection of an Approach or Airport Chart	83
11.2.5. Briefing with Approach Charts	85
11.2.6. Automatic Switch to corresponding Airport Chart	87
11.2.7. Procedures	87
11.2.8. MT-Blitzplan *	87
<b>12. MT-EFIS *</b>	<b>88</b>
12.1. Basics	88
12.2. Parameters for EFIS / Input Values	89
12.2.1. Values without flaps	90
12.2.2. Values with flaps	90
12.2.3. Example for a Calibration Flight	92
12.2.4. Settings Before Each Flight	92
12.2.5. QNH-Display	93
12.3. How to read the EFIS information	94
12.4. Elements in the Display	95
12.5. Error Messages	96
12.6. Limitations	96
12.7. WAAS/ EGNOS	97
<b>13. MT-TERRAIN EFIS *</b>	<b>98</b>
13.1. Requirements for MT-Terrain EFIS	98
13.2. Calibrating of Deviation to Pitch Axis (Button A)	98
13.3. Adjust Flight Attitude Display with GPS Attitude (Button R)	99
13.4. How does MT-Terrain EFIS Work?	99
<b>14. MT-TAWS Terrain Alert and Warning System *</b>	<b>100</b>
14.1. Display of TAWS relative to the Position	100
14.1.1. Warning in Flight Mode relative to GPS Altitude	100
14.1.2. Adjust the Elevation Warning Level in MAP Mode by → ALT + / → ALT -	102
14.2. TAWS as Synthetic Vision	102
14.2.1. Relative Warning with Synthetic Vision	103
14.2.2. Display of Terrain in Synthetic Vision (TAWS absolut)	104
<b>15. MT-Satellite Radar → RADAR</b>	<b>107</b>
15.1. Authentication for Downloads of Radar Pictures:	107

15.2. MT-Satellite Radar Standard.....	108
15.2.1. Adjust MT-Satellite Radar Standard.....	108
15.2.2. To Start MT-Satellite Radar Standard.....	108
15.3. MT-Satellite Radar Enhanced *.....	109
15.3.1. Adjust MT-Satellite Radar Enhanced.....	109
15.3.2. To Start MT-Satellite Radar Enhanced.....	109
15.4. Functions in RADAR Menu for optimized Handling.....	110
15.5. Display of the radar pictures.....	110
15.6. History – Recording of the Radar Pictures.....	112
15.7. Terminate MT RADAR.....	112
<b>16. MT-TCAS *</b> .....	<b>113</b>
16.1. Interface to Avidyne TAS 600/610/620 series.....	113
16.1.1 Switching MT-TCAS Monitoring On / Off.....	114
16.1.2. Display of the surrounding traffic sent by Avidyne on the chart.....	115
16.1.3. Display of Avidyne Data on Multi Function Display (MFD Mode).....	116
16.2. Interface to FLARM / PowerFLARM.....	117
16.2.1. MT-TCAS FLARM / PowerFLARM Monitoring On / OFF.....	119
16.2.2. Display of PowerFLARM Data on the chart.....	119
16.2.3. PowerFLARM Data in MFD Mode.....	120
16.3. Symbology for traffic display of Avidyne + FLARM.....	121
16.4. Symbols for data transmitted by ZAON XRX.....	122
<b>17. MT-Stormscope Interface*</b> .....	<b>123</b>
17.1. Switch on Stormscope display .....	123
17.2. Modes.....	123
17.3. Turn off Stormscope Mode .....	123
<b>18. MT-Autopilot Interface: Guidance Output *</b> .....	<b>124</b>
18.1. MT-Autopilot Guidance: Modi .....	124
18.2. AP-Guidance: Status display .....	125
18.3 Logic for Autopilot Guidance.....	125
<b>19. MT-Touch Screen *</b> .....	<b>126</b>
19.1. Move the Map with Fingertips to Desired Position.....	126
19.2. Selection of a Navigational Waypoint.....	126
<b>20. PDF Viewer</b> .....	<b>127</b>
<b>21. NVG Mode (Night Vision Goggles)</b> .....	<b>127</b>
<b>22. MT-Mission Management System *</b> .....	<b>128</b>
22.1. Components for the Mission Management System.....	128
22.1.1. Hardware.....	128

22.1.2. Contract for SBD (Short Burst Data).....	128
22.1.3. Contract with Rescue Track.....	128
22.2. Software.....	128
22.2.1. Basic information.....	128
22.2.2. Settings on the Moving Terrain System.....	128
22.3. MMS via Rescue Track on the Bildschirm .....	129
22.3.1. Description of the Screen.....	130
22.3.2. Incoming Messages.....	130
22.3.3. Recalling a message to the control center on the Moving Map.....	130
22.3.4. Selection of the Standardized Status Messages Using the Keys 2- 0.....	131
22.3.5. BACK.....	131
<b>23. MT-Video Input Device (MT Camera) *</b> .....	<b>132</b>
23.1. Technical Description.....	132
23.2. Operation MT Video Input.....	132
<b>24. MT-VGA Output Device *</b> .....	<b>132</b>
<b>25. Software Updates, OS Upgrade, Backup of User Data.....</b>	<b>133</b>
25.1. Information about the system.....	133
25.2. Software Update / Update of Charts and Data.....	134
25.2.1. Prerequisites.....	134
25.2.2. Procedure.....	134
25.3. Upgrade of the Operating System.....	135
25.3.1. Prerequisites .....	135
25.3.2. Info CPU Type.....	135
25.3.3. Procedure.....	135
25.4. Backup of User Data.....	136
25.4.1. Prerequisites.....	136
25.4.2. Procedure.....	136
25.4.3. Error Message.....	137
25.5 Restore of User Data.....	137
25.5.1. Procedure.....	137
<b>26. MT-OPS Database Editor *</b> .....	<b>139</b>
26.1. Purpose.....	139
26.2. Prerequisites.....	139
26.3. Installation.....	139
26.4. Usage.....	139
26.4.1. Editing waypoint data.....	140
26.4.2. Exporting waypoints to the VisionAir X.....	140
26.4.3. Loading the OPS database into the VisionAir X.....	141
26.5. Details on editing the OPS waypoints.....	143
26.5.1. Data format.....	143

25.6.2. Deleting waypoints.....	144
25.6.3. Inserting waypoints.....	144
25.6.4. Sorting waypoints.....	145
25.6.5. Searching for waypoints.....	145
<b>27. Autopilot Servo + Attitude + GPS Output *</b> .....	<b>146</b>
27.1. Purpose.....	146
27.2. Prerequisites.....	146
27.3. Configuration.....	146
27.4. Operation.....	146
27.5. Protocol Specification.....	146
27.5.1. Serial line configuration:.....	146
27.5.2 Packet format.....	147
27.5.3. Declaration of packet structure (C language).....	148
<b>28. Mission Management Program MT Operations Center 1.0.....</b>	<b>150</b>
28.1. Requirements.....	150
28.2. Diagram of functionality.....	150
28.3. General note for installation.....	150
28.4 Install MT OPS Center.....	151
28.4.1 Configuration.....	151
28.4.2 Usage.....	153
28.4.3 Main program window.....	153
28.5 Displaying target positions on Google Earth.....	155
28.5.1 Install Google Earth.....	155
28.5.2 Settings in Google Earth.....	155
28.6 How to extract data for "displaying target positions on customer's GIS".....	157

The chapters marked with an asterisk describe options which are not included in the standard version.

## 1. MT Basic

### 1.1. Power on MT VisionAir X and confirm the disclaimer with AGREE

The MT VisionAir X turns on automatically as soon as it is connected to permanent power (power supply or on board power). If the system runs on batteries it has to be switched on manually.

Use the button in right corner for switching ON / OFF the MT VisionAir X, press it for about 2-3 seconds.



Confirm the disclaimer by pressing AGREE.

If NO is pressed, a restart of the system is necessary.

Remark: The last configuration remains saved.

### 1.2. Positioning via GPS / related info in the Info Box

The MT VisionAir X starts in Flight Mode → the GPS position is displayed on the chart

If the chart is not positioned correctly check the Info Box.

To display Info Box choose → CHART (or → navWPT)

**NO DATA:** GPS not connected

**SATACQ:** GPS connected OK, reception too bad for positioning

**SATFIX 8:** Positioning, the subsequent number equals number of satellites in sight.  
Positioning possible from SATFIX 4 on

**DISTORTED:** Reception distorted or wrong protocol  
(check → AUX → SETUP → GPS)

MOVING TERRAIN <small>Air Navigation Systems AG</small>	
MODE	FLT 100%
	14:12:23
	SATFIX 8
	N 47 41.901'
	E 009 34.928'
ALT	2359 feet
GS [kts]	108 MT238
DCT	EDTO
DME [nm]	80.3 MC303
EET	00:44:36
SINGLE CHART	EDTO9 1
NXT	

### 1.3. Dimming the screen

Use the \* button in the left corner to dim the screen.

Repeated pressing improve the dimming, after 5 steps it returns stepwise to full brightness.

For control check the blue boxes in the screen.



**ATTENTION:** Dimming will be saved!

- If the system is powered off in the night mode the screen seem to be almost black when it is powered again in bright sunlight.
- Check the brightness by pressing the \* button!

## 1.4. Restart of MT VisionAir X (wait stead)

In case the MT VisionAir X has to be restarted, it is important to wait **at least 5 seconds** before rebooting.

If the restart is too fast, the boot process may not start correctly. The screen remains black and the following error message is displayed:

### 1. MT VisionAir X Systeme mit SP Board

"Reboot and Select proper Boot device  
or Insert Boot Media in selected Boot device and press a key"

### 2. MT VisionAir X Systeme mit TT Board

"EFI Shell version 2.00 [4.641]  
Current running mode 1.1.2  
map: Cannot find required map name."

Remark:


Check the type so -> AUX -> SETUP -> VERSION -> VERSION: Here you can find the information about SW and OS version, HW ID and the board type.

**This is a normal process!**


Wait for some seconds and start the system again.

## 1.5. Keyboard

### 1.5.1. Hot Keys - Flight Mode




### 1.5.2. Hot Keys – Map Mode



Comments: Camera needs to be set in the rights  
Birds View = Birds prospective in MT Terrain EFIS

Hotkeys always work only from the main menu

### 1.5.3. Positioning of chart using the arrow keys



The buttons Z / X and Y / 1 and 2 are allocated analog mirror-inverted.

## 1.6. Simulator mode

### 1.6.1. Switch on the simulator

Every MT VisionAir X provides a simulator mode  
→ AUX → TRACK → SIM ON

The simulator mode is labeled by SIMULATOR in a white, outlined red box.

### 1.6.2. Switch off the simulator mode

→ AUX → TRACK → SIM OFF

**Attention:** Make sure the simulator mode is stopped before flying.  
**The box SIMULATOR must be gone!**

### 1.6.3. Adjust the parameter in simulated flight

The simulated flight can be adjusted from the main menu:

**To adjust the flight altitude** – use hot keys

H higher (gradually + 100 ft)  
G lower (gradually - 100 ft)

**To adjust the speed** use

3 faster (gradually + 10 kts)  
4 slower (gradually -10 kts)

**To adjust the heading** use


L turn heading to left                      also X  
M turn heading to the right                also Y

Use the simulator mode for flight preparation.


We recommend to use the simulation mode to understand the explanations of functions and adjustments in this manual.

## 1.7. Symbols on the screen

### 1.7.1. Overview: Synchronized 2D / 3D



### 1.7.2. On the chart



#### Left part of the display (from top to bottom)

1. Ground speed (kts or km/h)
2. Information to interfaces to warning systems or displayed warnings:
  1. TCAS Traffic Collision Avoidance System
  2. TAWAS Terrain Alert and Warning System
  3. Stormscope

#### Right part of the display

1. UTC (via GPS)
2. Coordinates
3. Altitude (in ft) via GPS
3. Info to autopilot mode (autopilot direct, route or heading)
4. Direct: magnetic course, distance in nm and EET
5. Route information: Next waypoint, destination waypoint

#### Positioning symbols

1. Aircraft or helicopter symbol, position marked by the red dot

2. If GS is less than 2 kts: „Hover“ symbol
3. Loosing the GPS position „GPS SAT ACQ“
4. Off-center-mode shows more chart for the heading (switch to center-mode use → VIEW).
5. Trend vector: Length of the arrow varies according to scale and zoom factor, the distance between the red dot and the arrowhead is give, here 15 nm

The distance is either given

in cyan diamond (see picture)

→ course rose off


on the range rings

→ course rose on

6. DIRECT = light blue line
7. Routes are drawn with white vectors, the active leg turns magenta
8. Showing of the course rose → VIEW → CRS+, hide course rose → VIEW → CRS -)

### 1.7.3. Full Screen Terrain (Relief Dynamics)

(→ EFIS → TERRN)



The MT Terrain EFIS is displayed correctly from ground speed 39 kts on. If the speed is lower, the display is crossed out red.

### Left Part of the Display

1. CAS = Calibrated Airspeed (in kts or km/h), calculated from ground speed, climbing descending rate, air density and wind – with trend (yellow bars showing upwards / downwards)
2. Ground speed (kts or in km/h)
3. Information to connected warning systems or warnings:
  - TCAS Traffic Collision Avoidance System
  - TAWS Terrain Alert and Warning System
  - Stormscope

### Right Part of the Display

1. Altitude (in ft) from GPS with trend for climbing / descending (true altitude above MSL)
2. RA = Radar Altitude (in ft): distance between earth's surface and aircraft  
Up to an elevation of 490 ft above earth's surface the RA is visualized by linear function, from 490 ft on the visualization is logarithmic.
3. VS Vertical Speed: Climb (+) or descent (-) rate in FPM (feet per minute)
4. Info to autopilot (autopilot direct, route or heading)
5. Direct: Magnetic course, distance in nm and calculated arrival time


### Symbols for Attitude

1. Bank: Bank angle 10°, 20° (one dash each), 30° (triangle), 40°/45°/50° (dashes) and 60° (triangle)
2. BIRDY: Pitch trend = position in 2 minutes
3. Pitch: - white symbol with flaps (calibrated in EFIS settings)
  - red symbol without flaps
4. Horizontal line = altitude and elevation due to relation to the terrain
5. Magnetic Track in °
6. UTC (reception from GPS)

### Highway in the Sky

1. DIRECT: Light blue frames leading to the chosen DCT – in case of an airport pointing to the ARP = Airport Reference Point.
2. ROUTE: white frames, active leg: magenta frames
3. NEAREST Airport: Light green frames mark a virtual ILS:
  - length 7 nm from thresholds
  - angle: 3,5°

### 1.7.4. EFIS Horizon (→ EFIS → HORIZ)



The MT EFIS is displayed correctly from ground speed 39 kts on. If the speed is lower, the display is crossed out red.

#### Left Part of the Display

1. AOA = Angle of Attack (following the calibration data)
2. Flight Path Angle = slope of the aircraft in °
3. CAS = Calibrated Airspeed (in kts or km/h), calculated from ground speed, climbing descending rate, air density and wind – with trend (yellow bars showing upwards / downwards)
4. Ground speed (kts or km/h)
5. 2 MIN TURN = Standard Rate Turns 3° per second = 360° in 2 minutes


#### Right Part of the Display

1. Altitude (in ft) from GPS with trend for climbing / descending (true altitude above MSL)
2. RA = Radar Altitude (in ft): distance between earth's surface and aircraft  
Up to an elevation of 490 ft above earth's surface the RA is visualized by linear function, from 490 ft on the visualization is logarithmic.



### 1.7.6. Split Screen MT EFIS with Moving Map

→ EFIS → HORIZ → SPLIT




### 1.8. Function keys – general info

- 10 buttons below the screen are always related to the function from the menu above
- The function keys always advises what should be obtained
- In this user manual the function keys are marked by the prefix →
- Alternate (toggle) function keys = if a function is activated the function key shows the opposite function to provide the way back – they are marked by /
- Main Menu => right button = AUX
- → BACK => step back to the last menu or to the main menu
- → UP and → DOWN = move within a listing (always situated on button 8 and 9)
- → PREV and → NEXT = move from box to box

The functions for the buttons are only shown, if you purchased the rights to use the functions.

## 1.9. Symbols – general Info (Symbols on the Moving Map)

### 1.9.1. No Positioning from GPS



Position symbol in Map Mode = position in the center of the cross hairs.

If the chart is moved by using the green arrows in the upper corners the related cross hair gets colored green. The length of the green bar indicates the speed of the chart movement.



Warning Symbols for GPS reception (Flight Mode)

Satellite Acquisition but no positioning due to bad reception = improve the reception by moving to another position with improved sight to satellites



GPS data distorted = check the connection



No data from GPS = check the protocol

### 1.9.2. Position Symbols



“Hover“ symbol

GPS position correct but ground speed < 2 kts




Aircraft symbol

GS equals or greater than 2 kts  
red dots marks the position



Helicopter symbol (alternative) → AUX → SETUP → HELI / JET  
with revolving rotor



Trend vector

- optical projection of the track
- magnetic track given on the arrow head
- distance between position (red dot) and arrow head given in the cyan diamond (see picture)  
or over the range rings if the course rose
- Given in the chosen measurement unit (NM or metric)
- Length is related to the scale of the map and whether it is shown center / off center mode

### 1.9.3. Obstacles

Here is the symbol for version X.5.x and earlier. Symbolism from version x. 6.0 see chapter 4. MT Obstacles / obstacle representation



Obstacle (e.g. tower) 150 m AGL or higher, lighted



Obstacle (e.g. tower) lighted



Group of obstacles lighted



Obstacle (e.g. tower) marked or non marked



Group of obstacles (e.g. tower) marked or non marked



Wind turbine

RED Lines                      Wires / cables

BLUE Lines                    Power lines

### 1.9.4. Linear / Frame Symbols


- Cyan                          Direct
- White                        Route
- Magenta                     Active Leg

## 2. DIRECT / GO TO / NEAREST/ Defined Waypoints DEF

### 2.1. Direct

#### 2.1.1. Direct from NAV Waypoint Page

→ navWPT



**NAV WPT PAGE (VFR & IFR WAYPOINTS)**

**CURRENT WAYPOINT**

NAME: LUGANO

IDENT: LSZA | TYPE: APT

LAT: N 46 00.217' | LON: E 008 54.617'

ELEV: 915 FT

TWR "120,25; 122,55"; ILS01 108,90;  
TEL: 0916101111;  
RWY 01/19 1350m ASPHALT

**SEARCH**

LSZ

LSZA  
LSZB  
LSZC  
LSZE  
LSZF  
LSZG  
LSZH  
LSZI  
LSZJ  
LSZK  
LSZL  
LSZN  
LSZO  
LSZP

**MOVING TERRAIN**  
Air Navigation Systems AG

MODE: MAP 150%

13:45:57

SATACQ

N 45 50.929'  
E 008 49.818'

ALT 4986 feet

GS [kts] -- MT --

DCT ----

DME [nm] -- MC --

EET --:--:--

SINGLE CHART

NXT WPT ----

DME [nm] -- MC --

EET --:--:--

DEST ----

DME [nm] --


EET --:--:--

DBASE GOTO DCT DCT<sub>upd</sub> DCT<sub>tmp</sub> EDIT CHAR UP DOWN BACK

Insert DCT by typing ICAO code or name

→ DCT draws the DIRECT vector (blue)


- The blue direct vector remains at the position where it was inquired
- Displayed calculations follow the current position




- The blue line is maintained where it was requested

DCTLSZA MC018°  
7.0NM 03:49m


- The calculations are made from the specific position specified in the main menu
- Update the DIRECT via → DCTupd or Hotkey D from the main menu



Direct in Terrain EFIS



Direct in Terrain EFIS + 2D Moving Map (Split Screen)



### **2.1.2. Continuous DCT Update = Hotkey T**

Continuous update of the DCT vector Instead of static display:

- Hotkey T activates the continuous updating and liaises the DCT vector to the current position.
- Pressing hotkey T again releases the DCT vector from the position.

### **2.1.3. Temporarily Direct = DCTtmp**

- → DCTtmp: current position is the origin of the DCT and the blue line between the origin and the current position is constantly updated.
- By pressing → DCTtmp a TMPFIX waypoint is created simultaneously in the USER waypoint data base. It can be renamed if needed.

### **2.1.4. Direct to Waypoint in Routes**

Every waypoint in the route listings can be defined as DCT.


## **2.2. GOTO**

→ GOTO


- “Jumping“ to the chosen waypoint = automatically change to the MAP Mode
- back to FLIGHT mode (positioning by GPS) by hot key K or Z

## 2.3. Nearest Airports

### 2.3.1. Hot Key N shows the 3 Nearest Airports



Chose the NEAREST airports by using the hot keys 1 or 2 or 3 according to the given numbers in the background of the green panels.



### 2.3.2. NEAREST Airport in 2D = Information and Symbols


- ILS Symbol - runway direction elongated to 7 nm to both sides of the thresholds



Indication of

- ICAO code or name of the airport, if ICAO code is n/a.
- distance and true bearing
- elevation in ft
- length of runway max in m
- INFO frequency (1. given frequency in navWPT database)
- blue DCT leads to the Airport Reference Point

### 2.3.3. NEAREST in 3D = virtual ILS to the runway




Light green frames mark a virtual ILS:


- length 7 nm from thresholds
- angle 3,5°

### 2.3.4. Possibilities to display NEAREST


Display in Full 2D: → EFIS → MAP



Display in Split Screen (→ EFIS → TERRN)



Display in Full 3D:



### 2.3.2. Delete NEAREST

- press again hot key N

## 2.4. Defined Waypoints REF using Radial / DME

Waypoints are defined by entering distance and True Bearing relative to a reference point . This reference point is from one of the existing databases.

### 2.4.1. Pre-Settings for REF

1. Selection of the desired unit km or nm for the distance from the existing WPT

- AUX
- SETUP
- KM = switch to metric system, input in km
- NM = switch to nm system, input in nm

2. Define the database to select the reference point :

- navWPT
- DBASE

Selection of the desired database for the reference point  
e.g. Selection of VFRIFR Database

### DATABASE SELECTION

**CURRENT WAYPOINT**

NAME  
BERN-BELP

IDENT	TYPE
LSZB	APT

LAT	LON
N 46 54.733'	E 007 29.950'

ELEV  
510 m

INFO 125,125; TWR 121,025; ILS14  
110,10 IBE; TEL: 0319602111;  
RWY 14/32 1730m ASPHALT

**SEARCH**

BERN DME 14  
BERN LOC RW14.  
BERN SCHUEPFBERG NDB  
**BERN-BELP**  
BERNA  
BERNA  
BERNADT  
BERNARD HARBOUR  
BERNARD USFS  
BERNARDIN  
BERNAY SAINT MARTIN  
BERNE  
BERNE  
BERNE



MODE FLT 100%

08:36:34

INT-SIM

N 46 58.553'

E 007 24.932'

ALT 1229 m

GS [km/h] 111 MT 142

DCT ----

DME [km] -- MC --

EET ---:---:--

SINGLE CHART

NXT WPT ----

DME [km] -- MC --

EET ---:---:--

DEST ----

DME [km] --

EET ---:---:--

VFRIFR
USER
OFFSH
BER S
BRB S
SUI S
BACK

## 2.4.2. Define the RADIAL DME Waypoint

1. Selection of the reference waypoint within the preselected database, here VFRIFR.

NAV WPT PAGE (VFR & IFR WAYPOINTS)

<b>CURRENT WAYPOINT</b>		<b>SEARCH</b>	<b>MOVING TERRAIN</b> <small>Air Navigation Systems AG</small>
NAME BERN-BELP			MODE <b>FLT 100%</b>
IDENT LSZB	TYPE APT	BERN DME 14	08:37:21
LAT N 46 54.733'		BERN LOC RW14	<b>INT-SIM</b>
LON E 007 29.950'		BERN SCHUEPFBERG NDB	N 46 57.924'
ELEV 510 m		BERN-BELP	E 007 25.617'
INFO 125,125; TWR 121,025; ILS14 110,10 IBE; TEL: 0319602111; RWY 14/32 1730m ASPHALT		BERNA	ALT 1214 m
		BERNA	GS [km/h] 111 MT 141
		BERNADT	DCT ----
		BERNARD HARBOUR	DME [km] -- MC --
		BERNARD USFS	EET --:--:--
		BERNARDIN	<b>SINGLE CHART</b>
		BERNAY SAINT MARTIN	NXT WPT ----
		BERNE	DME [km] -- MC --
		BERNE	EET --:--:--
		BERNE	DEST ----
			DME [km] --
			EET --:--:--

DBASE
GOTO
DCT
DCTupd
DCTfmp
EDIT
CHAR
UP
DOWN
BACK

2. → EDIT

NAV WPT PAGE (VFR & IFR WAYPOINTS)

<b>CURRENT WAYPOINT</b>		<b>MOVING TERRAIN</b> <small>Air Navigation Systems AG</small>
NAME BERN-BELP		MODE <b>MAP 100%</b>
ID LSZB		14:18:12 AP
LAT N 46 54.733'		<b>SATACQ OFF</b>
LON E 007 29.950'		N 47 08.843'
COMMENT TWR 121,025; INFO 125,125; ILS14 110,10 IBE; TEL: 0319602111		E 007 15.598'
		ALT 9618 feet
		GS [kts] -- MT --
		DCT <b>LSZA</b>
		DME [nm] 96.7 MC 134
		EET --:--:--
		<b>SINGLE CHART LSZA11</b>
		NXT WPT ----
		DME [nm] -- MC --
		EET --:--:--
		DEST ----
		DME [nm] --
		EET --:--:--

NEW
REF
BACK

3. → REF

"REF" WAYPOINT (RADIAL/DME)		MOVING TERRAIN <small>Air Navigation Systems AG</small>
Geographic Coordinates (WGS84)		MODE MAP 100%
NAME BE14010		14:19:32 AP
ID                      True BRG                      Distance BE14010                                                                Nm		SATACQ OFF
From reference coordinates: (BERN-BELP / LSZB)		N 47 08.843'
N/S	N 46 54 733	E 007 15.598'
E/W	E 007 29 950	ALT 9618 feet
COMMENT		GS [kts] -- MT --
<div style="border: 1px solid black; height: 80px; width: 100%;"></div>		DCT LSZA
		DME [nm] 96.7 MC 134
		EET --:--:--
		SINGLE CHART LSZA11
		NXT WPT ----
		DME [nm] -- MC --
		EET --:--:--
		DEST ----
		DME [nm] --
		EET --:--:--
<span>SAVE</span> <span>GOTO</span> <span>DCT</span> <span>CHAR</span> <span>DEL</span> <span>PREV</span> <span>NEXT</span> <span>KM</span> <span>SWISSG</span> <span>BACK</span>		

- Enter the name by overwriting the automatically proposed WPTxxx
- ID is automatically " co-written "
- the reference point is ( here BERN\_BELP / LSZH ) and its coordinates ( here in LAT / LON system) is given above the ccoordinates.

4. → NEXT → NEXT

"REF" WAYPOINT (RADIAL/DME)		MOVING TERRAIN <small>Air Navigation Systems AG</small>
Geographic Coordinates (WGS84)		MODE MAP 100%
NAME BE14010		14:19:55 AP
ID                      True BRG                      Distance BE14010                      140                      10 Nm		SATACQ OFF
From reference coordinates: (BERN-BELP / LSZB)		N 47 08.843'
N/S	N 46 54 733	E 007 15.598'
E/W	E 007 29 950	ALT 9618 feet
COMMENT		GS [kts] -- MT --
<div style="border: 1px solid black; height: 80px; width: 100%;"></div>		DCT LSZA
		DME [nm] 96.7 MC 134
		EET --:--:--
		SINGLE CHART LSZA11
		NXT WPT ----
		DME [nm] -- MC --
		EET --:--:--
		DEST ----
		DME [nm] --
		EET --:--:--
<span>SAVE</span> <span>GOTO</span> <span>DCT</span> <span>CHAR</span> <span>DEL</span> <span>PREV</span> <span>NEXT</span> <span>KM</span> <span>SWISSG</span> <span>BACK</span>		

- Enter the True Bearing (3 digits)
- → NEXT
- Enter the distance in the selected unit (km or nm)

### 2.4.3. Work with RADIAL DME Waypoints


→ SAVE      save the Radial DME defined waypoint in the USER waypoint database

→ GOTO      display the def waypoint position on the map

or

→ DCT      define a direct to def waypoint





#### 2.4.4. RADIAL DME Defined Waypoint based on a User Waypoint

### NAV WPT PAGE (USER WAYPOINTS)

CURRENT WAYPOINT	
NAME BE14010	
IDENT BE14010	TYPE
LAT N 46 50.594'	LON E 007 35.024'
ELEV n/a	
n/a	

SEARCH
BE14010
BE14010
BODELSB
BODERSBERG
BURGBER
BURGBERG
EMMEN
EMMEN
GRUENTE
GRUENTENSEE
HIEFLA
HIEFLAU
HIRSCHG
HIRSCHGUND

MODE MAP 150%

NO DATA

N 46 50.594'  
E 007 35.024'

ALT 2296 m

GS [km/h] -- MT --

DCT BE1401

DME [km] 0.0 MC --

EET --:--:--

SINGLE CHART

NXT WPT ----

DME [km] -- MC --

EET --:--:--

DEST ----

DME [km] --

EET --:--:--

DBASE GOTO DCT DCTupd DCTtmp EDIT CHAR UP DOWN BACK

Selection of the USER waypoint database → navWPT → DBASE → USER

→ DEF

### "REF" WAYPOINT (RADIAL/DME)

Geographic Coordinates (WGS84)

NAME  
WPT004

ID                      True BRG                      Distance  
WPT004                                                                Nm

From reference coordinates: (BE14010 / BE14010)

N/S N    46    47    066                      E/W E    007    39    337

COMMENT

**MOVING TERRAIN**  
Air Navigation Systems AG

MODE MAP 100%

14:22:37 AP

SATACQ OFF

N 47 08.843'

E 007 15.598'

ALT 9618 feet

GS [kts] --    MT --

DCT BE1401

DME [nm] 27.1 MC142

EET ---:---:--

SINGLE CHART LSZA11

NXT WPT ----

DME [nm] --    MC --

EET ---:---:--

DEST ----

DME [nm] --

EET ---:---:--

SAVE GOTO DCT CHAR DEL PREV NEXT KM SWISSG BACK

- automatically the next " free " WPTxxx will be proposed .
- accept it → SAVE
- or change: it by entering a new name and overwrite the automatically proposed WPTxxx
- ID is automatically " co-written "
- the reference point (here BE14010 / BE14010 ) and its coordinates ( here in LAT / LON system ) is given on the screen

→ DCT

UTC 00:52:31  
 N 46 45.751'  
 E 007 40.162'  
 !! SIMULATOR !!


CHART   VIEW   nav/WPT   nav/RTÉ   T VIEW   EFIS   TAWS   RADAR   FPL   AUX

### 3. Special Coordinates \*

(Note.: Additional module, not included in the basic software)

In addition to the display of coordinates in the Latitude - Longitude system 's more coordinate systems are available:

→ navWPT → EDIT → NEW / MODIFY



Input and display of Coordinates in Latitude / Longitude

Switch to another coordinate system, here Swiss Grid

The choices are

LAT / LON


UTM

SWISSG      Swiss Grid

Once selected, a coordinate system remains active.

### 3.1. UTM

The Universal Transverse Mercator (UTM) conformal projection uses a 2-dimensional Cartesian coordinate system to give locations on the surface of the Earth. The system divides the Earth into sixty zones, each being a six-degree band of longitude, and uses a secant transverse Mercator projection in each zone.



**NEW USER WAYPOINT**

MODE FLT 75%

09:37:54

INT-SIM

32T PS

409 619

ALT 11626 feet

GS [kts] 110 MT27

DCT LIPB

DME [nm] 21.7 MC110

EET 00:11:50

SINGLE CHART LIPB11

NXT WPT ----

DME [nm] -- MC --

EET --:--:--

DEST ----

DME [nm] --

EET --:--:--

UTM Coordinates (WGS84)

NAME WPT003


ID WPT003

32T PS 432 617

COMMENT

SAVE GOTO DCT CHAR DEL PREV NEXT KM LATLON BACK

Conversion of waypoint coordinates in UTM



**NAV WPT PAGE (VFR & IFR WAYPOINTS)**

MODE FLT 75%

09:49:50

INT-SIM

32T PS

082 404

ALT 16469 feet

GS [kts] 110 MT208

DCT LIPB

DME [nm] 38.1 MC083

EET 00:20:47

SINGLE CHART LIPB11

NXT WPT ----

DME [nm] -- MC --

EET --:--:--

DEST ----

DME [nm] --

EET --:--:--

CURRENT WAYPOINT

NAME MUNCHEN

IDENT EDDM TYPE APT

LAT 32U QU LON 064 594

ELEV 1487 FT

INFO 123,125; TWR 118,700; 120,500; ILS08R 109,30; ILS26L 108,30; ILS08L 109,50; ILS26R 108,70; TEL: (089)975-21199; RWY 08L/26R 4000m CONCRETE

SEARCH EDDM

EDDM

EDDN

EDDN

EDDNA

EDDONTENAJON (CAR6)

EDDP

EDDP

EDDR

EDDR

EDDS

EDDS

EDDSFIELD


EDDT

UTM

DBASE GOTO DCT DCT<sub>upd</sub> DCT<sub>tmp</sub> EDIT CHAR UP DOWN BACK

### 3.1. Swiss Grid

The Swiss coordinate system (or Swiss grid) is a geographic coordinate system used in Switzerland for maps and surveying by the Swiss Federal Office of Topography (Swisstopo). The geodetic datum CH1903 (SRID 21781) uses as fundamental point the old observatory of Bern (46°57'3.9"N 7°26'19.1"E (WGS84)), the current location of the Institut für exakte Wissenschaften of the University of Bern. In order to avoid errors during coordinate transmissions, the coordinates of this point are 600'000 m E / 200'000 m N. The 0 / 0 coordinate is located near Bordeaux, France. Though E coordinate is denoted as y and N coordinate as x, E coordinate is the first axis of this Cartesian system, namely a point is denoted as (y, x). (Source: Wikipedia)



**NEW USER WAYPOINT**

SwissGrid Coordinates

NAME  
WPT003

ID  
WPT003

E 862 857    N 165 961

COMMENT

MODE FLT 75%

09:37:47

INT-SIM

E 860.844

N 166.117

ALT 11626 feet

GS [kts] 110 MT272

DCT LIPB

DME [nm] 21.5 MC110

EET 00:11:44

SINGLE CHART LIPB11

NXT WPT ----

DME [nm] -- MC --

EET --:--:--


DEST ----

DME [nm] --

EET --:--:--

SAVE GOTO DCT CHAR DEL PREV NEXT KM UTM BACK

Swiss Grid is only valid for CH, abroad CH switched to Lat / Lon system.



**NAV WPT PAGE (VFR & IFR WAYPOINTS)**

CURRENT WAYPOINT

NAME  
LUGANO

IDENT TYPE  
LSZA APT

EAST NORTH  
E 714.000 N 95.742

ELEV  
915 FT

INFO 121,175; TWR "120,250;  
122,550; 119,700"; ILS01 108,90; TEL:  
09 16 10 11 11;  
RWY 01/19 1420m ASPHALT

SEARCH  
LSZA

LSZA  
LSZB  
LSZC  
LSZE  
LSZF  
LSZG  
LSZH  
LSZI  
LSZJ  
LSZK  
LSZL  
LSZN  
LSZO  
LSZP

MODE FLT 75%

09:53:36

INT-SIM

E 823.571

N 132.124

ALT 19692 feet

GS [kts] 110 MT193

DCT LIPB

DME [nm] 41.8 MC075

EET 00:22:50

SINGLE CHART LIPB11

NXT WPT ----

DME [nm] -- MC --

EET --:--:--

DEST ----

DME [nm] --

EET --:--:--

DBASE GOTO DCT DCTupd DCTtmp EDIT CHAR UP DOWN BACK

## 4. MT-Obstacles \*

### 4.1. Coverage / Disclaimer and Updates

Database contains obstacles and line data (high-voltage cables and lifts) for the whole of Europe.

**Disclaimer:**

**MT does not guarantee the completeness and correctness of the data.**

The updates are performed via USB stick (data per download).

### 4.2. Displaying the obstacles: on / off

The obstacles are only visible from a certain zoom level onwards to ensure readability.  
→ VIEW → ZOOM + → Display the obstacles from 200% on the ICAO map on a scale of 1: 500,000 or on a map with a more detailed scale. Make sure that the base charts are arranged in a meaningful way.

To shown the obstacles:  
→ AUX → SETUP → OBST+

To disable the obstacles:  
→ AUX → SETUP → OBST-

The current setting is saved.

### 4.3. Representation of single or point obstacles

#### 4.3.1. 2D representation

The obstacles are represented pictorially in a rectangle surrounded by a black border.  
Unlit obstacles on **white** background:



- Unlit obstacle

Lighted obstacles on **yellow** background:



- Lighted obstacle

### 4.3.2. 3D view

An obstacle or - if specified - the icon is placed on the given coordinates.

At a greater distance, the obstacle is inflated and presented in a cuboid shape so that it can be better captured (this means it is larger than in reality). With an approximation to 2 km it is scaled with regard to the actual height of the obstacle and the visual representation is shown.




An illuminated obstacle flashes yellow (yellow point on the top of the obstacle).

Wind turbines are shown on a larger approach with a rotating rotor.

### 4.3.3. Table of individual obstacles (single or point obstacles)

Icon / 3D object	Def.Hgt	Symbols in former versions	Description / Notes
------------------	---------	----------------------------	---------------------

			<u>Antenna</u>
	80 m		<u>Bell tower</u>
			<u>Building</u>
	80 m		<u>Chimney / Smoke stack</u>
	80 m		<u>Communications tower</u>
	80 m		<u>Communication mast</u>
	80 m		<u>Cooling Tower</u>
	25 m		<u>Crane</u>
	30 m		<u>Gasometer</u>
	30 m		<u>Lighthouse</u>
	40 m		<u>Lighting pole</u>

	20 m		<u>Mast</u>
	40 m		<u>Mineshaft</u>
	30 m		<u>Observation tower/post</u>
	60 m		<u>Offshore platform</u>
			<u>Pole</u> Generic representation for single obstacle
	40 m		<u>Silo</u>
	80 m	 Height > 150 m  Lighted  Non-lighted  Group of lighted obstacles  Group of obstacles	<u>Tower (generic)</u>
	30 m		<u>Water tower / reservoir</u>

<p>2D: </p> <p>3D: combined object  </p>	150 m	<p>Wind turbine </p>	<p><u>Wind turbine</u></p> <p>Many wind turbines in EAD are incorrectly referred to as "windmill"</p>
	40 m		<p><u>Windmill</u></p>

## 4.4. Representation of cables and cables (linear obstacles)

### 4.4.1. 2D Representation

**High voltage power lines** are shown in yellow with **red masts**.

**Cables and lifts** are drawn in **red**.

**Temporary cables / ropes** are marked **blue**.

The "Wire Icon" - the image that specifies the type of cable - is displayed on the cable.

The masts of the high-voltage cables are red.

### 4.4.2. 3D Representation

The following components are required to display the cables in 3D:

1. The wires in the specified colors.
2. Masts and „auxiliary masts“ which guide the power lines and cables over terrain.

Here we have

Obstacle Type	Colour of the cable	Type of masts	Colour of masts	Representation for a distance bigger than 2 km	Representation at approximation < 2km
High voltage power line	yellow			1 yellow line	4 yellow lines
High voltage power line		masts coming from databases	red	red cuboid	red high voltage line mast
High voltage power line		auxiliary masts, necessary for guidance over terrain	blue	blue cuboid	red high voltage line mast
Cable/ rope	red				
Cable/ rope		masts coming from databases	red	red cuboid	red mast + icon
Cable/ rope		auxiliary masts, necessary for guidance over terrain	blue	blue cuboid	red mast + icon
Cable/ rope (temporarily)	blue				
Cable/ rope (temporarily)		auxiliary masts, necessary for guidance over terrain	blue	red cuboid	red mast

The „wire icon“ is displayed hanging on the rope.


#### 4.4.3. Table of linear obstacle

Wire Icon	Vertex 3D object / icon	Def.Hgt	Description / Notes
		40/60 m	<u>Power Line</u> Wires: 4 x yellow  <u>cable yellow</u>
	(Cuboid 1m x 1m x 20m, Red) scaled to obs height	15 m	<u>Bridge</u> same as susp.bridge


N/A	Cuboid (1m x 1m x 20m, Red) scaled to obs height		<u>Cable</u> Wires: 1 x red  Generic representation for linear obstacle  <b>cable red</b>
		30 m	<u>Cable Car ("Gondelbahn")</u> Wires: 1 x red  <b>cable red</b>
		20 m	<u>Cable crane ("Materialbahn")</u> Wires: 1 x red  <b>cable red</b>
		15 m	<u>Temporary material lift</u> Wires: 1x blue  <b>cable blue</b>
		20 m	<u>Chair Lift</u> Wires: 1 x red  <b>cable red</b>
		25 m	<u>Gondola Lift ("Kabinenbahn")</u> Wires: 1 x red  <b>cable red</b>

		12 m	<p>Ski-Lift ("Schleplift") Wires: 1 x red</p> <hr style="border: 2px solid red;"/> <p>cable red</p>
	<p>Cuboid (1m x 1m x 20m, Red) scaled to obs height</p>	15 m	<p>Suspension Bridge Wires: 1 x red</p> <p>Icon stretched between poles and to pole height Single wire on top of poles</p> <hr style="border: 2px solid red;"/> <p>cable red</p>
--	<p>Cuboid (1m x 1m x 20m, Red) scaled to obs height</p>		<p>Telephone Line Wires: 1 x red</p> <hr style="border: 2px solid red;"/> <p>cable red</p>

Visualization in 2D



Visualization in 3D



## 5. CHARTS


### 5.1. Base Charts

Charts covering big areas (like whole continents)

→ CHART → BASE chose the desired chart by moving the the pointer with UP or DOWN and confirm with → USE.

#### 5.1.1. Automatic switch to the next chart by using ZOOM

The display is horizontally split by a dashed line:



BASE CHART SELECTION		MOVING TERRAIN Air Navigation Systems AG	
#09: EUROPE ICAO 1:500 000 ZOOM 50%		MODE	FLT 150%
#08: EUROPE ICAO 1:500 000 (HI RES)			11:00:57
#15: SWISS TOPO 1:100 000, COPYRIGHT: SWISSTOPO			INT-SIM
#16: SWISS TOPO 1:50 000, COPYRIGHT: SWISSTOPO			N 46 45.965'
-----			E 007 43.820'
#12: GERMANY GENERAL CHART WITH FLIGHT SAFETY INFORMATION 1:200 000		ALT	35703 m
#13: ITALY GENERAL 1:200 000		GS [km/h]	111 MT 165
#04: BAVARIA 1:50 000		DCT	17020
#11: GERMANY 1:100 000		DME [km]	13.5 MC 213
#00: .MFD		EET	00:07:18
#02: AUSTRIA VFR 1:200000 ED.14 (FREYTAG/BERNDT&ARTARIA KG 1230 VIENNA)		SINGLE CHART	
#01: AUSTRIA 1:50 000		NXT	
#03: BADEN WÜRTTEMBERG 1:50 000 TOP 50		WPT	----
#05: BELGIUM AERONAUTICAL CHART 1:250 000 (2014)		DME [km]	-- MC --
#06: CENTRAL ASIA (PAKISTAN, INDIA, NEPAL, BANGLADESH) TPC 1:500 000		EET	--:--:--
#10: FRANCE GENERAL 1:200 000		DEST	----
#14: SOUTH AMERICA TPC/ONC 1:500 000		DME [km]	--
#07: DEUTSCHE FLICHT NOTRUF 1:275 000		EET	--:--:--
			

#### Above the line:

Maps which are embedded in the logic switch function by pressing ZOOM

#### Underneath the line:

further charts

#### How to use the function “Automatic Switch To The Next Chart”

By pressing → ZOOM+ or → ZOOM- in → VIEW menu the chart with the more (or less) detailed scale will be displayed automatically.

**Requirements:**

The charts which you want to see automatically must be sorted in the area above the dashed line. Use → movUP and → movDN to move the charts.

**5.1.2. Order of the Charts**

Choose the chart you want to move by → UP or  
→ DOWN

Move the chart within the list by → movUP or  
→ movDN

**Above the dashed line** → order of the chart is mandatory due to the logic!

**The chart with the biggest scale to the top  
then the next further detailed scale!**

The 1. chart will be (for almost all customers using the system in Europe)

EUROPE ICAO 1:500 000 ZOOM 50%

followed by

EUROPE ICAO 1:500 000 (HI RES).

The 3. chart will be the next detailed e.g.

GERMANY GENERAL CHART... 1:200 000

and then e.g.

BAVARIA 1:50 000


**Underneath the line** → order of the charts is optional

– order may be improved due to ease of access.

**.MFD = Multi Function Mode = display without map**

This chart option cannot be sorted into the logic section, since the MFD “chart” cannot be linked to a scale. It must be available for all ranges.

### 5.1.3. Base Chart Selection



**BASE CHART SELECTION**

#06: EUROPE ICAO 1:500 000 ZOOM 50%

#05: EUROPE ICAO 1:500 000 (HI RES)

#07: GERMANY GENERAL CHART WITH FLIGHT SAFETY INFORMATION 1:200 000

#11: SWISS TOPO 1:50 000, COPYRIGHT: SWISSTOPO

-----

#00: .MFD

#02: AUSTRIA VFR 1:200000 ED.14 (FREYTAG/BERNDT&ARTARIA KG 1230 VIENNA)

MODE FLT 100%

16:04:29

SATAcq

N 46 59.798'

E 010 27.243'

ALT -----

GS [kts] -- MT --

DCT ----

DME [nm] -- MC --

EET --:--:--

SINGLE CHART LIPB09

NXT

WPT ----

DME [nm] -- MC --

EET --:--:--

DEST ----

DME [nm] --

EET --:--:--

SING.CH USE AWY + movUP movDN UP DOWN BACK

By choosing a base chart from the upper section with → USE the automatic ZOOM logic is activated at the same time.

The subsequent ZOOM steps are:

for EUROPE ICAO 1:500 000 ZOOM 50%

75% → 100%, then switch to

EUROPE ICAO 1:500 000 (HI RES)

for this and all subsequent following charts:

75% → 100% → 150% → 200%

The most detailed chart = the last chart above the dashed line can be zoomed in up to 600%.

Charts underneath the line can be selected by → USE

- no automatic switch to the next chart!
- Zoom steps from 75% - 600%

#### No chart – only gray background

The selected base chart does not cover the area of the position:

- check the position
- switch to another chart, either by selecting another chart or using the ZOOM

## 5.2. Single Chart Selection (Approach Plates are typical Single Charts)

→ CHART → SIN.CH

Select the category by pressing → << or → >>

# SINGLE CHART SELECTION

SID	STAR	APPROACH	APT
OTHERS	VFR	HELI-GER	VFR-GER
	OVERVIEW	VAC-CH	

	BOLZANO
LIPB11	LOC DME RWY 01
LIPB31	
LIPB910	
LIPB911	
LIPB912	

**MOVING TERRAIN**  
Air Navigation Systems AG

MODE **FLT 100%**

**08:52:19**

**INT-SIM**

**N 46 21.515'**

**E 008 06.207'**

**ALT 1562 feet**

GS [kts] **160** MT **177**

DCT **LIPB**

DME [nm] **133** MC **085**

EET **00:50:03**

SINGLE CHART **LIPB09**

NXT

WPT **----**

DME [nm] **--** MC **--**

EET **--:--:--**

DEST **----**

DME [nm] **--**

EET **--:--:--**

BASE
GOTO
SHOW
SEL
UNSEL
<<
>>
DOWN
BACK

- Selection: type identifier or name - just use the alphabetical keyboard
- the preview facilitates the orientation to select the suitable plate
- → SEL : selection of the chart, it will be displayed automatically as soon as you will enter the area for which it is referenced.
- Coming closer to this area the single chart will initially be displayed embedded in the scale of the base chart. As soon as the single chart will be reached it will be displayed full scale automatically.
- The info box informs about the currently selected single chart (use e.g. → navWPT)

### 5.2.1. VFR Approach Charts (JeppView)

Select the category VFR by → << or → >>

- Enter the identifier or name of the airport - just by using the alphanumeric keyboard –





Scale of the VFR Approach Chart

- In case no VFR approach chart is selected: The airport which is located next to the current position is suggested.
- In case a VFR approach chart is selected, the pre-selection is maintained

## 5.2.2. VFR Approach Plates of Deutsche Flugsicherung (German Flight Safety)

Category HELI-GER: helicopter landing sites (DFS), sorted by names

Category VFR-GER: Approach patterns (DFS) sorted by ICAO 4-Letter Codes

Name without amendment    Approach pattern

Amendment \_A and \_A2            Area Chart

Amendment \_T                      Taxi Chart

(for airports with runways longer than 2000m)

# SINGLE CHART SELECTION

SID	STAR	APPROACH	APT
OTHERS	VFR	HELI-GER	VFR-GER
	OVERVIEW	VAC-CH	

EDMK
EDME
EDME_A
EDMF
EDMG
EDMH
EDMI
EDMJ
EDMK
EDML
EDMN
EDMO
EDMO_T
EDMP

**MOVING TERRAIN**  
Air Navigation Systems AG

MODE **FLT 100%**

09:01:11

SATACQ

N 46 04.006'

E 008 17.648'

ALT 17905 feet

GS [kts] -- MT --

DCT **MASERA**

DME [nm] 4.3 MC007

EET --:--:--

SINGLE CHART **LI1391**

NXT WPT ----

DME [nm] -- MC --

EET --:--:--

DEST ----


DME [nm] --

EET --:--:--

BASE	GOTO	HIDE	SEL	UNSEL	<<	>>	UP	DOWN	BACK
------	------	------	-----	-------	----	----	----	------	------

### 5.2.3. Overview, Europe overview chart, USA overview chart

- category OVERVIEW: EUROPE (USA)
- to study long routes
- for weather briefing over a big area
- the Europe overview chart is technically laying on top of the base chart = e.g. ICAO chart. Since it is not easily possible to “leave” the chart (it is covering all Europe!) it has to be deselected:
- **To deselect the overview chart use → CHART → HIDE or → UNSEL !**



#### 5.2.4. Automatic Pre-selection of Single Charts

- If a route is present in the navRTE page (manually typed in or coming from BlitzPlan):
  - SIDs for the departure airport are pre-selected
  - STARs and APPROACHs for the destination airport are pre-selected
- If no route is present in the navRTE page:
  - APT = Airport chart of the Nearest airport is pre-selected

## 6. VIEW – Adjustment of the Display

### 6.1. → ZOOM (see chapter 3.1. Base Charts)

Button provides info about what you aim:

- |          |                          |
|----------|--------------------------|
| → ZOOM - | zoom out                 |
| → ZOOM + | zoom in                  |
| → 100%   | chart in size 100% scale |

### 6.2. Aircraft Symbol Center or Off Center

- |                   |  |
|-------------------|--|
| → CENTR / → OFF-C | Move your position center / off center |
|-------------------|--|

### 6.3. Chart Track Up or North Up

- |            |   |
|------------|---|
| → ROTATE / | chart s displayed / rotated to track or |
| → N-UP     | north up                                |

The 3D Relief Dynamics formerly placed in this menu is now here:

- EFIS → TERRN

### 6.4. → MFD


Switch to MFD Mode = automatic selection of the .MFD “map”.

- ZOOM+
- ZOOM -
- 100% = 472nm Center Mode und 600nm im Off-Center Mode

back to the chart → MAP

Attention:

TCAS- and stormscope data are display relative to the position. It is not possible to show the warning data if the aircraft is not moving.



Attention:

TCAS and Stormscope data are determined by the board sensor system.

If there is no movement and therefore no heading, the determined data can not be displayed (positioned), even on the map. See instructions in "Installation manual".

#### 6.4.1. Why do we need the MFD mode?

- To display long routes
- Weather briefing along the route  
Weather briefing for big areas
- Enroute layer without the chart information
- In general to determine information without the chart, especially for bigger ranges

## 7. NAV Waypoint Page → navWPT

### 7.1. Standard data bases

VFR/IFR data base

**NAV WPT PAGE (VFR & IFR WAYPOINTS)**

<b>MODE</b> FLT 300%	
<b>10:44:37</b>	
<b>INT-SIM</b>	
<b>N 53 04.296'</b>	
<b>E 008 20.884'</b>	
<b>ALT 15992 feet</b>	
<b>GS [kts] 160 MT265</b>	
<b>DCT ----</b>	
<b>DME [nm] -- MC --</b>	
<b>EET ---:---:--</b>	
<b>SINGLE CHART EGPLL11</b>	
<b>NXT WPT EGPLL</b>	
<b>DME [nm] 337 MC256</b>	
<b>EET 02:06:23</b>	
<b>DEST EGPLL</b>	
<b>DME [nm] 337</b>	
<b>EET 02:06:23</b>	

<b>CURRENT WAYPOINT</b> NAME FRIEDRICHSHAFEN  IDENT      TYPE EDNY      APT  LAT              LON N 47 40.283'    E 009 30.683'  ELEV 1368 FT  INFO 129,60; TWR "120,07; 134,30"; ILS06 111,90; ILS24 111,90; TEL: (07541)284120; RWY 06/24 2356m ASPHALT	<b>SEARCH</b> EDNY  EDNY EDNZ  EDO EDOA EDOB EDOBE EDOC EDOCU EDOD EDODI EDODU EDOE EDOF	
---	--	--

**INS WPT PAGE (VFRPT)**

<b>MODE</b> FLT 300%	
<b>10:47:36</b>	
<b>INT-SIM</b>	
<b>N 53 05.116'</b>	
<b>E 008 07.771'</b>	
<b>ALT 14965 feet</b>	
<b>GS [kts] 160 MT285</b>	
<b>DCT ----</b>	
<b>DME [nm] -- MC --</b>	
<b>EET ---:---:--</b>	
<b>SINGLE CHART EGPLL11</b>	
<b>NXT WPT ----</b>	
<b>DME [nm] -- MC --</b>	
<b>EET ---:---:--</b>	
<b>DEST ----</b>	
<b>DME [nm] --</b>	
<b>EET ---:---:--</b>	

<b>CURRENT WAYPOINT</b> NAME FRIEDRICHSHAFEN  IDENT      TYPE ECHO  LAT              LON N 47 44.700'    E 009 33.600'  ELEV n/a NYE	<b>SEARCH</b> FRIED  FRIEDRICHSHAFEN FRIEDRICHSHAFEN FRIEDRICHSHAFEN FRIEDRICHSHAFEN FRIHAM  FRITZLAR FRITZLAR FRITZLAR FRITZLAR FRITZLAR FRITZLAR FRITZLAR FRITZLAR FRITZLAR	
--	--	--

**NAV WPT PAGE (VFR & IFR WAYPOINTS)**

<b>MODE</b> FLT 300%	
<b>10:44:37</b>	
<b>INT-SIM</b>	
<b>N 53 04.296'</b>	
<b>E 008 20.884'</b>	
<b>ALT 15992 feet</b>	
<b>GS [kts] 160 MT265</b>	
<b>DCT ----</b>	
<b>DME [nm] -- MC --</b>	
<b>EET ---:---:--</b>	
<b>SINGLE CHART EGPLL11</b>	
<b>NXT WPT EGPLL</b>	
<b>DME [nm] 337 MC256</b>	
<b>EET 02:06:23</b>	
<b>DEST EGPLL</b>	
<b>DME [nm] 337</b>	
<b>EET 02:06:23</b>	

**INS WPT PAGE (VFRPT)**

<b>MODE</b> FLT 300%	
<b>10:47:36</b>	
<b>INT-SIM</b>	
<b>N 53 05.116'</b>	
<b>E 008 07.771'</b>	
<b>ALT 14965 feet</b>	
<b>GS [kts] 160 MT285</b>	
<b>DCT ----</b>	
<b>DME [nm] -- MC --</b>	
<b>EET ---:---:--</b>	
<b>SINGLE CHART EGPLL11</b>	
<b>NXT WPT ----</b>	
<b>DME [nm] -- MC --</b>	
<b>EET ---:---:--</b>	
<b>DEST ----</b>	
<b>DME [nm] --</b>	
<b>EET ---:---:--</b>	

Search input by 4 letter identifier

**INS WPT PAGE (VFRPT)**

<b>MODE</b> FLT 300%	
<b>10:47:36</b>	
<b>INT-SIM</b>	
<b>N 53 05.116'</b>	
<b>E 008 07.771'</b>	
<b>ALT 14965 feet</b>	
<b>GS [kts] 160 MT285</b>	
<b>DCT ----</b>	
<b>DME [nm] -- MC --</b>	
<b>EET ---:---:--</b>	
<b>SINGLE CHART EGPLL11</b>	
<b>NXT WPT ----</b>	
<b>DME [nm] -- MC --</b>	
<b>EET ---:---:--</b>	
<b>DEST ----</b>	
<b>DME [nm] --</b>	
<b>EET ---:---:--</b>	

<b>CURRENT WAYPOINT</b> NAME FRIEDRICHSHAFEN  IDENT      TYPE ECHO  LAT              LON N 47 44.700'    E 009 33.600'  ELEV n/a NYE	<b>SEARCH</b> FRIED  FRIEDRICHSHAFEN FRIEDRICHSHAFEN FRIEDRICHSHAFEN FRIEDRICHSHAFEN FRIHAM  FRITZLAR FRITZLAR FRITZLAR FRITZLAR FRITZLAR FRITZLAR FRITZLAR FRITZLAR FRITZLAR	
--	--	--

**NAV WPT PAGE (VFR & IFR WAYPOINTS)**

<b>MODE</b> FLT 300%	
<b>10:44:37</b>	
<b>INT-SIM</b>	
<b>N 53 04.296'</b>	
<b>E 008 20.884'</b>	
<b>ALT 15992 feet</b>	
<b>GS [kts] 160 MT265</b>	
<b>DCT ----</b>	
<b>DME [nm] -- MC --</b>	
<b>EET ---:---:--</b>	
<b>SINGLE CHART EGPLL11</b>	
<b>NXT WPT EGPLL</b>	
<b>DME [nm] 337 MC256</b>	
<b>EET 02:06:23</b>	
<b>DEST EGPLL</b>	
<b>DME [nm] 337</b>	
<b>EET 02:06:23</b>	

**INS WPT PAGE (VFRPT)**

<b>MODE</b> FLT 300%	
<b>10:47:36</b>	
<b>INT-SIM</b>	
<b>N 53 05.116'</b>	
<b>E 008 07.771'</b>	
<b>ALT 14965 feet</b>	
<b>GS [kts] 160 MT285</b>	
<b>DCT ----</b>	
<b>DME [nm] -- MC --</b>	
<b>EET ---:---:--</b>	
<b>SINGLE CHART EGPLL11</b>	
<b>NXT WPT ----</b>	
<b>DME [nm] -- MC --</b>	
<b>EET ---:---:--</b>	
<b>DEST ----</b>	
<b>DME [nm] --</b>	
<b>EET ---:---:--</b>	

Search input by name

### 7.1.1. Hints for waypoint search

- you type in the field in the right part of the screen
- check in the left part, whether it is the correct waypoint
- check coordinates or identifier


### 7.1.2. Mistype?

- For mistype to empty the field → DOWN, then new entry or
- → CHAR → DEL to delete only 1 character
- Use → CHAR (character) for special characters ( . , - / @ )

### 7.1.3. Switch to other waypoint data bases

- → DBASE selection of data bases
  - VFR/IFR = navigational data base worldwide  
detailed info for European airports
  - USER = open USER data base for your own WPTs
  - VFRRPT = VFR Report Points

It is possible to integrate further data bases.



**INS WPT PAGE (VFRRPT)**

**CURRENT WAYPOINT**

NAME: FRIEDRICHSHAFEN

IDENT: ECHO TYPE: [ ]

LAT: N 47 44.700' LON: E 009 33.600'

ELEV: n/a

NYE: [ ]

**SEARCH**

FRIED

FRIEDRICHSHAFEN

FRIEDRICHSHAFEN

FRIEDRICHSHAFEN

FRIEDRICHSHAFEN

FRIHAM

FRIEHLAR

**MOVING TERRAIN**  
Air Navigation Systems AG

MODE: FLT 300%

10:47:36

INT-SIM

N 53 05.116'

E 008 07.771'

ALT: 14965 feet

GS [kts]: 160 MT 285

DCT: ----

DME [nm]: -- MC --

EET: --:--:--

SINGLE CHART: EGLL11

NXT WPT: ----

DME [nm]: -- MC --

EET: --:--:--

DEST: ----

DME [nm]: --

EET: --:--:--

DBASE INS INSPOS EDIT CHAR UP DOWN BACK

#### **7.1.4. Direct (q.v. 2.1.)**

- → DCT select the destination → NavWPT from one of the data bases → DCT
- → DCTupd direct update (only available if the destination is already selected)  
also hot key D
- → DCTtmp temporarily direct

#### **7.1.5. Delete Direct**

- use → AUX → SETUP → DCT-

### **7.2. User Waypoints (use → EDIT)**

#### **7.2.1. To enter a new waypoint → NEW**

- current position is automatically entered
- new waypoint named WPTxxx is offered
- type in the new name (the system name will be deleted)
- → NEXT type in the identifier: it will be displayed on the chart (flag)
- → SAVE

#### **7.2.2. Modify an existing waypoints → MODIFY**

- type the correct data and → SAVE

#### **7.2.3. Delete a waypoint which is no longer needed → ERASE**

this deletes the waypoint definitely from the data base.

USER waypoints can be DCTs or parts of the routes.

#### **7.2.4. REF Waypoint defined by Radial DME (see 2.4)**

## 7.3. Further Waypoint databases

### 7.3.1. VFR reporting points

The VFRRPT database contains VFR reporting points in Europe.

Search for the the airport name (not the ICAO identification!).

Further selection via the IDENT field in which the specification (e.g., ECHO, NOVEMBER, etc.) is found.

Procedure for inserting a waypoint from the VFRRPT e.g. as DIRECT:

→ navWPT → DBASE → VFRRPT → Select the point → DCT

**Attention:**

The selected database remains active. If you want to use a waypoint from one of the other databases, you have to change the database again.

→ navWPT → DBASE → Change the database (for example to VFR IFR) → Select the new waypoint → DCT.

### 7.3.2. Streetdata

Site and streetdata are especially used for airborne rescue operations.

Here an example of the database „Bayern“:

→ navWPT → DBASE → BAV S

## DATABASE SELECTION

**CURRENT WAYPOINT**

NAME  
FRIEDRICHSHAFEN

IDENT	TYPE
EDNY	APT

LAT                      LON

N 47 40.283'        E 009 30.683'

ELEV

1368 FT

TWR "120,07; 134,30"; INFO 129,60;  
ILS06 111,90; ILS24 111,90; TEL:  
(07541)284120;  
RWY 06/24 2356m ASPHALT

**SEARCH**

EDNY

---

EDNY

EDNZ

EDO

EDOA

EDOB

EDOBE

EDOC

EDOCU

EDOD

EDODE

EDODI

EDODU

EDOE

**MOVING TERRAIN**  
Air Navigation Systems AG

MODE MAP 100%

NO DATA

N 47 13.863'  
E 012 42.844'

ALT 9623 feet

GS [kts] -- MT 219

DCT EDNY

DME [nm] 133 MC 280

EET --:--:--

SINGLE CHART

NXT WPT ----

DME [nm] -- MC --

EET --:--:--

DEST ----

DME [nm] --

EET --:--:--

VFRIFR
USER
OPS
VFRPT
BAV S
BDW S
BACK

Selection of the city or the location using the keyboard → SEL

## LOCATION SELECTION(STREETS (BAV))

**SEARCH**

SULZBERG

---

SULZBERG

SULZBERG (ERLBACH)

SULZBERG...(SEEG)

SULZBERG-RIED...(SULZBERG)

SULZBRUNN...(SULZBERG)

SULZBUERG (MUEHLHAUSEN)

**MOVING TERRAIN**  
Air Navigation Systems AG

MODE MAP 100%

NO DATA

N 47 13.863'  
E 012 42.844'

ALT 9623 feet

GS [kts] -- MT 219

DCT EDNY

DME [nm] 133 MC 280

EET --:--:--

SINGLE CHART

NXT WPT ----

DME [nm] -- MC --

EET --:--:--

DEST ----

DME [nm] --

EET --:--:--

SEL
DEL
SPACE
.
-
UP
DOWN
BACK

Selection of the street / address

### NAV WPT PAGE (bav-S / SULZBERG)

**CURRENT WAYPOINT**

NAME  
SPARENBERG

IDENT      TYPE

LAT      LON

N 47 41.034'    E 010 20.915'

ELEV  
n/a

PLZ: 87477  
NR: 2

**SEARCH**

SP

SPARENBERG

STEINGADEN

STEINGADEN

STEINGADEN

STEINGADEN

STEINGADEN

STEINGADEN

STEINGADEN

STEINGADEN

STEINGADEN

STELLENMOOS

STELLENMOOS

STRASSOESCH

**MOVING TERRAIN**  
All Navigation Systems AG

MODE MAP 100%

NO DATA

N 47 13.863'  
E 012 42.844'

ALT 9623 feet

GS [kts] -- MT 219

DCT EDNY

DME [nm] 133 MC 280

EET --:--:--

SINGLE CHART

NXT WPT ----

DME [nm] -- MC --

EET --:--:--

DEST ----

DME [nm] --

EET --:--:--

DBASE
GOTO
DCT
DCTu0bd
DCTt0mp
EDIT
CHAR
UP
DOWN
BACK

This waypoint can be used as a „normal“ waypoint, for example as a direct:



- insert of the complete name or identifier = **just continue typing**
- → INS = insert
  
- → UP and → DOWN move up / down in the list:  
Mark a WPT: The next waypoint will be entered **above** this position.

Repeat this procedure till you entered all WPT for the routing.

- → DEL delete a single WPT from the route

Every route WPT can be used for

- → GOTO jump to this position on the chart
- → ICPT intercept: for route optimizing
- → DCT Direct

## 8.2. Switch to another data base

Type the **1. character of the WPT you want to select!**

- INS WPT PAGE
- → DBASE select → VFR/IFR  
→ USER
  
- input / selection by identifier or name = **continue typing**
- → INS = insert

## 8.3. Insert of current position in the flightplan

To insert the current position or the position on the chart in the route:

Move the chart to the desired position (approach WPT, airspace or others) by using the arrow keys or touch function.

- → navRTE
- set the active position marker to the WPT above which you want to enter the position by → UP and → DOWN
- type any character key (A, B, C, ...) = INS WPT PAGE
- → INSPOS Insert Position (coordinates given in the INFO BOX)
- coordinates are inserted in the route

## 8.4. Save, Load, Modify and Delete → ROUTES

Routes can be

- saved → SAVE
- load → LOAD
- modified
- deleted → ERASE = deleted from the unit completely

Routes can contain IFR elements - the name VFR routes is fact not very precise.

### **!!! IMPORTANT !!!** **Additive loading of route segments**

Clear the route page before compiling a new route:

→ AUXrte → CLR or → DEL (multiple presses if needed)

Blitzplan routes are always loaded exclusively.

## 8.5. → AUXrte – further functions for planning a route

- entry of cruise flight levels and the cruise speed (type the numbers ) for EET calculation
- → CLR delete all WPTs from the route
- → INV invert the route (only customized route, no procedures)
- → copy ALT copy altitude from GPS
- → copy GS copy ground speed from GPS

## 9. Further Functions → AUX

### 9.1. → TRACK: Track Saving and Automated Logbook

#### 9.1.1. Track recording → AUX → TRACK

Tracks are recorded as soon as the GS > 2 kts

- SAVE save the track by typing a name
- PLAY replay the track in time lapse (→ NORM or → FAST)
- ERASE delete completely
- CLEAR delete the track points from the display

#### 9.1.2. Logbook → AUX → TRACK

- LOG = Log book
- EDIT work with the flight logs
  - separate buttons for special characters
  - PREV and → NEXT = move from field to field
  - SAVE the entries (back to EDIT page)
- INS insert a new line = new flight
- ERASE final delete of an entry line
- TXT file export, see 7.3 → AUX → SYS
- UP and → DOWN = selection of an entry for editing

## 9.2. → SETUP: Adjustment / Indication of Configuration Parameters

### 9.2.1. Software version

- AUX → SETUP → VERSION the current version number is displayed
  - 1 x press: SW version
  - 2 x press: version of operating systems and further details

### 9.2.2. Switch to metric measurement units

- AUX → SETUP → KM switches to metric units (back with → NM)
- AUX → SETUP → NM switches to nm (back with → KM)

### 9.2.3. Date of the Obstacle Data

→ AUX → SETUP → DATES

### 9.2.4. Hiding of Info to Clear up the Screen (i.e. Delete of the DIRECT)

→ AUX → SETUP → WPT- /+      show / hide of User WPT symbols  
 → AUX → SETUP → DCT-          un-select the Direct  
 → AUX → SETUP → OBST- /+      hide / show the obstacle symbols

### 9.2.5. GPS Selection

→ GPS                    selection between EXTERN and INTERN  
 → EXTERN  
     • INTEGRAL GPS                    (4800, NMEA)  
     • FAST INTEGRAL GPS                (9600, NMEA)  
     • TRIMBLE                            (9600, AVIATION)  
     • KING KNL90                        (9600, AVIATION)  
     • GARMIN 430/ 530                  (9600, AVIATION)  
     • UNIVERSAL FMS                  (9600, AVIATION)  
     • FLARM (38400, NMEA) (ONLY FOR COMBINED TCAS  
       DISPLAY)  
 → INTERN                integrated SIRF 4 GPS

### 9.2.6. Selection of Phone / Download

→ AUX → SETUP  
 → DIAL UP                    selection for downloads (radar pictures / BlitzPlan)  
  
 → USE                        selection of source  
 → RadDWD /  
     RadENH                    download of radar pictures (MT-Satellite Radar)  
 → RadAuth                    input of authentication data for MT-Satellite Radar  
  
 → HNG-UP                    manual disconnect of the data connection

**NOTE:** BlitzPlan will hold the line for 180 sec. to provide a fast access to further downloads. If the works is already done it is advisable to hang up manually to save costs, especially for the use of Iridium.

### Arranging the required telephone sources


- Selection via → UP  
→ DOWN
- Move the selection within the list via → movUP  
→ movDN

**Above the line: The telephone source (s) that are necessary for the setting** (usually 1 satellite phone and a SIM definition).

**Below the line: More sources optional.**

### 9.2.7. Switch between Jet or Heli Symbol

- JET
- HELI



### **9.3. → AUX → SYS → BACKUP / Restore or Transfer of User Data**

#### **→ AUX → SYS**

→ BACKUP a current backup of:

- USER waypoints / routes / tracks
- Logbook
- Blitzplan FPL list and log in data
- saved PDFs
- current settings for display and system

Use an USB Stick (FAT32 formatted)

Report of progress and end of backup on the screen.

→ RESTORE restores the data from the backup USB stick  
to synchronize several MT-VisionAir systems

### **9.4. → AUX → RESET**

Restructuring of the data bases

- followed by an automatic restart of the program (duration ca. 30 sec.)
- fixes very rare data base problems

## 10. Flightplan / Route Transmission \*

### 10.1. Transmission of a Flight plan from Garmin 430 (XFILL- Option)

Prerequisite: Connection via COM Port to Garmin 430.

→ **navRTE** → **XFILL**

**Transmission of the current flightplan at the time of the crossfill request into the MT.**

Displayed in the Nav Route Page.

The functions DCT / ICPT / GOTO can be used to every waypoint.

### 10.2. Transmission and Displaying of a User Route from an External Flightplanning Program

Transmission via USB stick.

Prerequisite: the USB stick has to be formatted FAT32.

#### 10.2.1. Work with external Flightplanning Program

- Compile a route
- Save on the USB stick in GPX format – directly in the root directory
- The name of the route should be maximum 8 characters (e.g. 4Lettercode Departure + 4Lettercode Destination = EDJAEDNY)

#### 10.2.2. Transmission to MT-VisionAir X

Insert the USB stick into any USB connector of the MT-VisionAir X. We recommend to use an external USB port via central connector, so the unit itself remains installed.

The unit may be already running, there is no need to shut it down nor restart.

→ **navRTE** → **ROUTES** → **IMPORT**

List of routes on the USB stick is displayed and imported.

```

-- Route import from USB memory --
EDJAEDNY.gpx          -> imported as EDJAEDNY
LIAPLIRU.gpx         -> imported as LIAPLIRU
EDNMLZPE.GPX        -> imported as EDNMLZPE

3 routes imported

```

Unplug the USB stick after import.

**CAUTION:** Any route files already present on the VisionAir X with the same name will be overwritten without confirmation

### 10.2.3. Load the Route

→ navRTE → ROUTES → LOAD

The imported routes can then be found in the navRTE - ROUTES page, ready to be loaded into the navRTE page using the LOAD button:

ROUTES PAGE

ROUTE to LOAD/SAVE/DEL

Existing ROUTEs

EDJAEDNY

EDNMLZPE

LIAPLIRU


IMPORT
LOAD
SAVE
ERASE

### 10.2.4. Display of the Route in the NAV RTE Page and on the Chart

NAV RTE PAGE

WAYPOINT ID	ALT	MC	LEG DIST	TOT DIST	LEG TIME	EET
EDJA		---	0	0	00:00	00:00
JAS		166	5	5	00:03	00:03
WANGEN		231	21	27	00:13	00:16
NYS		242	11	38	00:07	00:24
EDNY		319	5	43	00:03	00:27

On the chart:




### 10.2.5. Error Messages using IMPORT Function

When giving the IMPORT command and no USB stick has been inserted, or if the USB memory cannot be read, the unit shows the following message:



In case no route files (in known format) are found:



When route files are found but cannot be interpreted:

```

-- Route import from USB memory --

EDNLLOWI.gpx          -> FORMAT ERROR

0 routes imported
    
```

### 10.2.6. Example of GPX file recognized by the VisionAir X

```

<?xml version="1.0" encoding="UTF-8"?>
<gpx xmlns="http://www.topografix.com/GPX/1/1"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" version="1.1"
xsi:schemaLocation="http://www.topografix.com/GPX/1/1
http://www.topografix.com/GPX/1/1/gpx.xsd">
  <rte>
    <name>EDJA-EDNY</name>
    <rtept lat="47.988822" lon="10.239483">
      <sym>EDJA</sym>
      <name>Memmingen</name>
    </rtept>
    <rtept lat="47.903333" lon="10.266667">
      <sym>JAS</sym>
      <name>EDJA VRP SIERRA</name>
    </rtept>
    <rtept lat="47.691277" lon="9.841347">
      <name>Wangen</name>
    </rtept>
    <rtept lat="47.608333" lon="9.586667">
      <sym>NYS</sym>
      <name>EDNY VRP SIERRA</name>
    </rtept>
    <rtept lat="47.671317" lon="9.511486">
      <sym>EDNY</sym>
      <name>Friedrichshafen</name>
    </rtept>
  </rte>
</gpx>
    
```

**NOTES:**

- 1) The <sym> field determines the waypoint identification as shown in the VisionAir X
- 2) The <name> field is ignored, unless the <sym> field is absent. In this case the <name> field is used as waypoint identification (see "Wangen" in the example route)

## 11. MT-IFR Complete Package \*

### 11.1. MT-ENROUTE Layer \*

Display of the Airway-Layer

→ CHART → AWY+ → BACK

Hide the Airway Layer

→ CHART → AWY- → BACK

#### 11.1.1. MT-Enroute Layer without chart (MFD mode)



To only see the Enroute Layer :


→ CHART → AWY + → BACK and  
→ VIEW → MFD

Set a suitable scale by using the ZOOM function. If the scale is too large the Enroute map is not shown, the info would be unreadable.

## 11.1.2. MT-Enroute Layer over the ICAO charts

Back to charts

→ VIEW → MAP



## 11.2. Electronic Flight Bag

Select IFR JeppView charts

→ CHART → SIN.CH Single Chart Selection

Categories are:

**SID** Standard Instrument Departures  
Type: not referenced, no moving maps due to drawing not to scale

**STAR** Standard Arrivals  
Type: not referenced, no moving maps due to drawing not to scale

**APPROACH** Standard Approaches  
Type: Moving Maps

**APT**            Airport Charts  
                  Type: Moving Maps

**OTHERS**       Further charts

### **11.2.1. Selection / Alteration of an active airport**

Conditions:

If a route is entered in → navRTE:

- departure airport is active for category SID
- all other categories are allocated to the destination airport

Alteration of the active airport by typing the identifier or name = **just type**

IFR APT SELECTION → complete the identifier / name of the airport or select by → UP or → DOWN

Select with → SEL

### **11.2.2. Selection of a Category SID STAR APPROACH APT OTHERS**

Select a category by → << or → >>

### **11.2.3. Selection and Displaying of a SID or STAR or Information**

Choose the right chart within the list with → UP or → DOWN.

The title of the chart is displayed in the header above the maps preview, here ALBIX 1C, 1D & 2R DEPS.

## SINGLE CHART SELECTION

SID	STAR	APPROACH	APT
OTHERS	VFR	HELI-GER	VFR-GER
	OVERVIEW	VAC-CH	

MODE **MAP 150%**

NO DATA

**N 47 27.483'**

**E 008 32.883'**

**ALT 6155 feet**

GS [kts] -- MT --

DCT ----

DME [nm] -- MC --

EET ----

**SINGLE CHART EDTO91**

NXT ----

WPT ----

DME [nm] -- MC --

EET ----

DEST ----

DME [nm] --

EET ----

ZURICH

ALBIX 1C, 1D & 2R DEPS

BASE
SHOW
SHOW
UNSEL
<<
>>
UP
DOWN
BACK


Select the previewed chart → SEL

Charts which are not referenced can be displayed

→ SHOW

and zoomed

→ VIEW → ZOOM+ or → ZOOM-



To end the displaying of the chart → CHART → UNSEL


### 11.2.4. Selection of an Approach or Airport Chart

- choose the category by → >>
- choose the chart within the list by → UP or → DOWN or typing the name
- check the preview
- check the title of the chart given in the header

SINGLE CHART SELECTION

SID	STAR	APPROACH	APT
OTHERS	VFR	HELI-GER	VFR-GER
	OVERVIEW	VAC-CH	

	INNSBRUCK
LOWI11	LOC DME EAST
LOWI12	<small>LOC DME EAST (LOC OUTBOUND) CONTINUE ON 075° WITH MAX GRADIENT AT D14.0 OEV HOLD AT 7500'   WARNING: be aware of back course indication on reciprocal track</small>
LOWI13	<small>By Elev: 07 170'   Terrain level: By ATC   Terrain alt: By ATC</small>
LOWI14	
LOWI21	
LOWI220	
LOWI221	
LOWI9 10	
LOWI9 11	



MODEMAP 100%

NO DATA

NO GEO REFERENCE

ALT 6155 feet

GS [kts] -- MT --

DCT ----

DME [nm] -- MC --

EET ----:----

SINGLE CHART LOWI02

NXT

WPT ----

DME [nm] -- MC --

EET ----:----

DEST ----

DME [nm] --

EET ----:----

BASE
GOTO
SEL
<<
>>
DOWN
BACK

Select by → SEL

As soon as the area for this chart will be arrived the chart will be displayed

- initially embedded in the base chart and as soon it is really arrived
- to scale as a moving map.


Even if the distance to the chart is too big and it cannot be displayed it is already prepared for the use and will come up automatically.

**Attention:** If the ground speed is lower than 65 kts, the corresponding AIRPORT CHART will be selected automatically.


Advantage: No need for further entries during landing phase.

Disadvantage: Approach chart may not be displayed long enough (slow approaches).

2D map




Split screen → EFIS → TERRN → SPLIT




### 11.2.5. Briefing with Approach Charts

As soon as an Approach Chart is selected the main menu provides briefing possibility:


- TVIEW = Top View
- PVIEW = Plan View
- VVIEW = Vertical View
- POS = back to current position and moving map function
  
- T VIEW = to read information above the map



→ P View = map itself – centered and fully readable




→ V View = vertical approach information



→ POS = back to current position and moving map function

### 11.2.6. Automatic Switch to corresponding Airport Chart

Ground speed < 65 kts → automatic switch to the APT Chart



Here display split screen with MT Terrain EFIS.

### 11.2.7. Procedures


IFR procedures are no longer maintained or updated.  
Possibly existing procedures are outdated and not for navigational use.

### 11.2.8. MT-Blitzplan \*

Separate user manual for Blitzplan can be downloaded here: [www.blitzplan.de](http://www.blitzplan.de).


## 12. MT-EFIS \*

### 12.1. Basics



Pitch rotation along the lateral axis

Roll rotation along the longitudinal axis i.e. the bank.



Pitch of the aircraft is combined flightpath and angle of attack AOA.

The angle of attack is the angle between flow direction of air particles and reference axis of the aircraft. The flow direction is the opposite of the flightpath.

The angle of attack depends of several variable parameters.

It is essential to customize some parameters individually for each airplane.


## 12.2. Parameters for EFIS / Input Values

To enhance the accuracy of EFIS display some values have to be determined during a calibration flight.

1. AOA Angle of Attack depending on the speed.

To read the Angle of Attack on the on board gyro horizon, the flightpath has to be horizontal, then AOA matches the pitch.

This is achieved at a horizontal flight without a change in altitude. A total of eight measured values is necessary:



not MTOW (maximum take off weight) but current weight for calibration flight

### 12.2.1. Values without flaps

Min Speed Clean:


Minimum speed above stall speed = ca. 5 kts above stall speed

AOA Clean:

Corresponding value of the angle of attack in degrees for minimum speed clean.

Read it directly on the artificial horizon during horizontal flight.

If you look at the artificial horizon below it would be read as 4°. Copy this value to field "AOA CLEAN". Copy the corresponding "MIN SPEED CLEAN" from the airspeed indication (IAS).



Max Speed Clean:

IAS at horizontal flight with no indicated pitch.

The pitch symbol coincides with the line of the horizon = neutral line.

### 11.2.2. Values with flaps

Measurement according to the description for evaluation without flaps.

Min Speed Flaps:

Minimum speed above stall speed with flaps (ca. 5 kts above stall speed)

AOA Min Speed Flaps:

Corresponding value of the angle of attack in degrees for minimum speed with flaps.

Max Speed Flaps:

Maximum speed with flaps

**AOA Max Speed Flaps:**

Corresponding value for angle of attack (in degrees) for maximum speed with flaps.

The pilot decides whether to choose:

- Max Flap Setting or
- i.e. To & Approach Flap Setting.

The white symbol corresponds to the chosen value setting.

**Weight:**


Take off weight for the calibration flight (in kg).

This values in combination with the GPS data allow a continuously calculation of AOA and current pitch.

2 different symbols for the different settings:

- red pitch symbol for the flight without flaps
- white pitch symbol for the flight with flaps.

The following diagram corresponds with the configuration from the example above.



### 12.2.3. Example for a Calibration Flight

The following procedure is an example for a calibration flight:

At medium airspeed a horizontal flight is set without a change in altitude. Now the speed is reduced as far as possible (e.g. 1.1 x stall speed). Copy the measured data for Angle of Attack and IAS in a prepared table.

Now accelerate until you can see the zero-line on the (adjusted) on-board horizon. This value is copied into the table as well.

The same maneuver is flown with flaps set. There you accelerate until you reach the maximal flyable speed and then copy the pitch.

The altitude of the flight is not relevant, but it is advantageous to perform the calibration flight in a stable atmosphere.

After that you can easily enter the data into the MT unit. The predefined default values will be overwritten and the new data will be saved.


With EFIS activated you find the input menu when you press → SET.  
To save the data, use → STORE.

Take-Off Weight:	[kg]		
Min Speed Clean, IAS =	[kts]	AOA Clean =	[deg]
Max Speed Clean, IAS =	[kts]	AOA = 0	[deg]
Min Speed Flaps, IAS =	[kts]	AOA Min Speed Flaps:	[deg]
Max Speed Flaps, IAS =	[kts]	AOA Max Speed Flaps:	[deg]

### 12.2.4. Settings Before Each Flight

→ FLIGHT input mask for wind and weight.

These data should be as up to date as possible as they influence the dynamic calculations. According to feasibility and circumstances this data can be updated during the flight as well. But even with a poor calibration, the display stays "relatively" correct. Only the absolute calculation of the pitch shows a minor discrepancy.




Enter the current data of wind speed, direction of wind and the weight. As a default value the weight from the calibration flight is entered. If no data is entered, the system calculates with wind=0 and the default standard weight. The settings can be updated during the flight.

Save values by pressing → STORE.

### 12.2.5. QNH-Display

By use of the exact height measurement of the GPS and the barometric altimeter of the aircraft the current QNH can be calculated very accurately. For this you set the atmospheric pressure of your altimeter to 1013 hPa. Open the input mask with the button → QNH.



Now you copy the value from the altimeter in feet (Flight Level Display). After pressing → STORE the current reference QNH is calculated for the area you are flying.

### 12.3. How to read the EFIS information

To show several flight conditions at the same time there are several reference markings. In the horizon there are 3 different symbols:

- 1.) The red aircraft symbol is the reference for Pitch under normal conditions (without flaps). It is visible from the minimal clean speed onwards.
- 2.) The white symbol shows the pitch attitude with the position of the flaps for which the EFIS was calibrated. It is visible from the minimal speed with flaps set to the maximal speed with flaps set. The values 1.) and 2.) also depend on the take-off weight.
- 3.) The blue symbol visualizes the angle of the flight path. It stays always in the center of the pitch-scale where the Flight Path Angle (Slope) can be read.


At a very low speed only the white symbol is shown. When the red marking is added, the display references itself to the pitch without flaps. This is the reason for a skip in the display.

In turning flight:

The roll angle is shown on the white scale at the top of the display. The gradation has the following increment (from the inside to the outside):

- Roll Angle = 10 degrees (first narrow bar)
- Roll Angle = 20 degrees (second narrow bar)
- Roll Angle = 30 degrees (first triangle)
- Roll Angle = 40 degrees (short bar)
- Roll Angle = 45 degrees (longer bar)
- Roll Angle = 50 degrees (short bar)
- Roll Angle = 60 degrees (second triangle)

## 12.4. Elements in the Display



- 1) The value in the display corresponds (with correct calibration) to the Angle of Attack.
- 2) The yellow bar visualizes the speed trend. That implies the expected acceleration in 10 secs (+- kts).
- 3.) This is the display for the ground speed (kts) and the CAS (kts). The CAS it the air

speed calculated by EFIS, which depends on the ground speed, change of height, air density and wind.

- 4.) The Flight-Path-Angle corresponds to the flight path, i.e. the slope of the aircraft. The point of the aircraft-symbol shows the current value. In the example the aircraft is in a horizontal position, so the slope (FPA) is zero.
- 5.) The indicator of the Two-Minute-Turn shows the mark where the turning rate of a 360° turn is exactly two minutes.
- 6.) Below the display of the horizon is the display of the Mag Track. This shows the current track over ground.
- 7.) After input of the current pressure (see chapter 4) this window shows the reference value of the current QNH.
- 8.) RA = Radar Altitude. The value shown here is the distance between the aircraft and the ground. In order to achieve a high sensitivity when flying close to the ground, up to a height of 490 ft above ground the altitude data is visualized by a linear function. Above 490 ft the display switches to logarithmic.
- 9.) This shows the true altitude over MSL.
- 10.) Variometer in right part of the screen = climbing rate respectively descending rate in ft/min.

## 12.5. Error Messages

- |                           |  |
|---------------------------|--|
| - NO DATA:                | No Data received by EFIS                               |
| - LOADING DATA:           | Data is loading (about 2 sec after being switched on)  |
| - display crossed out red | low speed, minimum 39 kts                              |
| - ALTITUDE ERROR:         | Wrong or no ALTITUDE data                              |
| - SIGNAL ERROR:           | Error in data transmission respectively wrong GPS-data |

## 12.6. Limitations

EFIS does not work properly for low speed aircraft (e.g. gliders) and not for aircraft which can be subject to uncoordinated conditions of flight (e.g. helicopters).

Inaccuracy in the display can occur...

- ... because of evident changes of the wind conditions coinciding with a low airspeed

- ... yawning flight (e.g. engine failure in a twin aircraft)
- ... in the post-stall area
- ... with some acrobatic flight maneuvers

## **12.7. WAAS/ EGNOS**

With systems like EGNOS and the fully compatible system WAAS, correction signals are transmitted on the frequency L1 of the geostationary satellites like Inmarsat or Artemis

This correction data is acquired from a multitude of stationary ground stations which collect the ionospheric induced run time errors within their reception area and calculate the correction factors for different geographical areas.

This allows the EGNOS / WAAS compatible GPS receivers to determine the additional run time effects of the signals in the ionosphere and the resulting divergence of the positioning is less than 1 m.

Without this correction data the standard accuracy of civil GPS lies between 5 m and 15 m.

EGNOS is a joint project of ESA, the EU and the European air traffic control Eurocontrol, which initialize this project together as European Tripartite Group (ETP). The European Satellite Service Provider (ESSP) will put EGNOS on the market and run it as a business.

At the moment the system is in transition from test mode to routine mode.

List of satellites with an EGNOS transponder:

ARTEMIS (PRN 124; ID 37)

Inmarsat AOR-E (PRN 120; ID 33)

Inmarsat IOR-W (PRN 126; ID 39)

## 13. MT-TERRAIN EFIS \*

The combination of internal position sensor with the positioning on the Fast Integral GPS enables an indication of the attitude in real time.

The presentation is in full- or split-screen, with or without terrain representation (Terrain or Horizon).

The explanation of the screen representations in Chapter 1.7.

The limitations are to re-evaluate the addition of the internal position sensor.

MT-TERRAIN EFIS has been successfully tested in several helicopter flights.

### 13.1. Requirements for MT-Terrain EFIS

The internal calibration must be done at the factory and MT have taken the appropriate activation.

#### Use in the cockpit:

- The MT-VisionAir must be firmly attached to the aircraft. An installation on the controls is not possible.
- The MT-VisionAir X must be mounted aligned to the aircraft axis.
 

<b>No deviation angles</b>	to	latitude axis	=	y axis	=	roll
and		yaw axis	=	z axis	=	heading.
- A **deviation angle** to the lateral axis = x axis = pitch can be compensated.

### 13.2. Calibrating of Deviation to Pitch Axis (Button A)

It is possible to display the aircraft attitude (not that of the MT-VisionAir!) on MT VisionAir X systems that are not mounted completely vertically.

After installation of the MT-X VisionAir the "Mounting angle" must be determined:

Select → EFIS → HORIZ → Press the button "A".

The MT-VisionAir will confirm the measurement with a message.

**IMPORTANT: The aircraft must be on a level surface and must not be moved.**

"A" in → EFIS → HORIZ is deactivated as soon as the GPS Speed > 5 kts in order to avoid unwanted calibration in flight.

Should it become necessary due to compensate an unusual situation on the ground (eg tail dragger ...), give us a call.

The calculated mounting angle is stored. To adjust this setting is only necessary again if the installation situation changes or the MT-VisionAir X will be installed in another aircraft.

### **13.3. Adjust Flight Attitude Display with GPS Attitude (Button R)**

"R" adjusts the displayed flight attitude with the flight attitude from the Fast Integral GPS.,

### **13.4. How does MT-Terrain EFIS Work?**

- MT EFIS Terrain combines flight attitude data from the internal sensors with flight attitude data based on the Fast Integral GPS. The sensors provide immediate response to change in position, the GPS provides a stable attitude with slow response.
- The MT TERRAIN EFIS starts at a speed of about 40 kts. At lower speeds, the instrument is marked with a red cross and a level attitude is shown (this value is assumed).
- To get a reliable result, it is important to define appropriate speeds and angles of attack:  
→ EFIS → HORIZ → SET


## 14. MT-TAWS Terrain Alert and Warning System \*

### 14.1. Display of TAWS relative to the Position

#### Parameter

red	opaque	terrain - (read "position minus") 200 ft and higher
yellow	semi transparent	terrain - 200 bis - 400 ft
green	semi transparent	terrain - 400 bis - 600 ft

#### 14.1.1. Warning in Flight Mode relative to GPS Altitude




On the chart (ICAO 1:500 000):

→ TAWS → ON, relative mode, FLT mode


TAWS cannot be displayed:

- if altitude is not transmitted
- without movement in flight mode

Missing altitude causes a completely red screen!




- TAWS → ON + → EFIS → TERRN: full screen, relative mode, FLT mode
- In MT Terrain Mode the warning colors the 3 dimensional terrain
  - Here display in birds view : use hot key V



- TAWS → ON + → EFIS → TERRN: Split screen, relative mode, FLT mode + birds view = hot key V.

### 14.1.2. Adjust the Elevation Warning Level in MAP Mode by → ALT + / → ALT -

- Use it for simulation of cloud base
- 500 ft steps to adjust the simulated altitude



→ TAWS → ON + → EFIS → TERRN: Split Screen, TAWS relative, MAP mode.

### 14.2. TAWS as Synthetic Vision


Display of Synthetic Vision under **2 conditions** possible:

→ TAWS → ON + → VIEW → MFD


Back to TAWS on the “real” chart:

→ VIEW → MAP

### 14.2.1. Relative Warning with Synthetic Vision



→ TAWS → ON + → VIEW → MFD + → EFIS → TERRN (here V for birds view)



→ TAWS → ON + → VIEW → MFD + → EFIS → TERRN, Split Screen (here V for birds view)

### 14.2.2. Display of Terrain in Synthetic Vision (TAWS absolut)


→ TAWS → ON → ABS + → VIEW → MFD

Different possibilities to display the terrain:

Full Screen (→ EFIS → MAP)




Split Screen (→ EFIS → TERRN)




Advantage of Synthetic Vision

- Zoom out possible to see big ranges
- Overview over long routes


→ TAWS → ON → ABS → Zoom – (press several times)



Zoomed in for detailed information (→ VIEW → ZOOM+)



→ TAWS → ON → ABS + → EFIS → TERRN



Advantage of this display:

Combination of detailed view in 3D and overview over the routing.

De-activate TAWS by → TAWS → OFF.

## 15. MT-Satellite Radar → RADAR

### 15.1. Authentication for Downloads of Radar Pictures:

→ AUX → SETUP → DIAL-UP → AUTH

DWD AUTHORIZATION		MOVING TERRAIN Air Navigation Systems AG 		
DWD FTP Username:	<input type="text" value="Lf"/>	MODE	FLT 150%	
DWD FTP Password:	<input type="password"/>		11:18:12	
Flugwetter.de Username:	<input type="text"/>		INT-SIM	
Flugwetter.de Password:	<input type="password"/>		N 46 39.867'	
			E 008 03.623'	
			ALT 40184 m	
			GS [km/h] 111 MT 060	
			DCT 17020	
			DME [km] 32.9 MC 269	
			EET 00:17:45	
			SINGLE CHART	
			NXT WPT ----	
			DME [km] -- MC --	
			EET --:--:--	
			DEST ----	
			DME [km] --	
			EET --:--:--	
SAVE	DEL	CAPS	NEXT	BACK

- I → CAPS capital letters
- NEXT next field
- PREV previous field
- DEL delete 1 character
- SAVE save input of authentication data

## 15.2. MT-Satellite Radar Standard

### 15.2.1. Adjust MT-Satellite Radar Standard

→ AUX → SETUP → DIAL-UP → RadDWD

(note: button shows now RadENH) 

### 15.2.2. To Start MT-Satellite Radar Standard

→ RADAR Start of the downloads

#### 2 Operating Modes

→ ON (→ RADAR → ON)

- starts an automatic dial up and download process for the radar pictures in time intervals (at time every 15 min)
- finishes the process with an automated hang up.

→ M.LOAD (→ RADAR → M.LOAD)

Manual on time download – dial up, download, hang up

#### Stop the downloads:

→ RADAR → RAD OFF

## 15.3. MT-Satellite Radar Enhanced \*

Full European Coverage  
Combined with lighting data



### 15.3.1. Adjust MT-Satellite Radar Enhanced

→ AUX      → SETUP      → DIAL-UP → RadENH

(note: button  shows now RadDWD)

### 15.3.2. To Start MT-Satellite Radar Enhanced

→ RADAR      To start the downloads

## 2 Operating Modes

→ RADAR → ON

- starts an automatic dial up and download process for the radar pictures in time intervals (every 15 min)
- finishes the process with an automated hang up.

→ M.LOAD (→ RADAR → LiveRad)

Manual download in between the regular automatic interval

- dial up, download, hang up

### Stop the downloads:

→ RADAR → RAD OFF

## 15.4. Functions in RADAR Menu for optimized Handling

→ SHOW / → HIDE show or hide the radar picture overlay

→ ZOOM+ and ZOOM -

→ MFD switch to Multi Function Display for display for big ranges  
back to the chart by → MAP

→ DIAL-UP selection of the phone / download option

→ UP and → DOWN → USE

→ HNG-UP hanging up - normally the hanging up is done automatically.

- only necessary in case the download process is lasting too long (i.e. for bad reception)


## 15.5. Display of the radar pictures

Intensity of precipitation in MT color scale.


The traffic light colors allow an intuitive understanding of the intensity and danger

- green = in the clouds: coarse dropped condensed humidity  
below the clouds: little rain
- yellow = medium intensity of precipitation
- red = strong precipitation, likely forming of CB s
- blue = extreme strong precipitation, very active CB s, hail

On the chart




In MFD Mode (here together with Enroute Layer)



Further optimizing displaying the radar → VIEW

→ ZOOM+ and → ZOOM- to evaluate the radar pictures along the routing



- CENTR / → OFF-C      position centered or off centered
- ROTATE / N-UP      Track UP or chart north up



Info for the radar layer on the screen  
Info to the download process

### 15.6. History – Recording of the Radar Pictures

- The radar pictures are saved and can be displayed consecutively:
- << back to older radar pictures
  - >> forward to more current radar pictures
    - allows a weather briefing over a longer period, i.e. already for preflight briefing
    - allows also a (cautious) estimate of weather development

### 15.7. Terminate MT RADAR

- RADAR → OFF
  - The status windows stays as long as the radar picture is displayed.
  - To terminate the display of the radar picture use → RADAR → HIDE

## 16. MT-TCAS \*

### 16.1. Interface to Avidyne TAS 600/610/620 series


#### Dynamic synchronized simulation technology DSS

As soon as other air traffic has been detected in the vicinity, a simulator is activated in parallel. It is calibrated to and analyzes the flight characteristics of the respective aircraft. This enables the pilot to determine at a glance the direction and speed (15-second arrow = trend vector) of approaching aircraft.

Each aircraft with transponder recognition is individually interrogated and analyzed by the sensor. This produces a transparent picture of surrounding air traffic.

#### The critical cylinder

Moving Terrain places a "critical cylinder" around your own aircraft.



- The radius of the critical cylinder is 1 nm.
- Its height is 1000 feet.
- The vertical position of your own aircraft in the critical cylinder depends on the current flight path:

Own flight path	Relative altitude in feet	
	above	below
Normal flight	> 500	< -500
Climb	> 1000	
Decent	> 0	< -1000



### 16.1.2. Display of the surrounding traffic sent by Avidyne on the chart



On the left half of the screen      TCAS AVIDYNE OK  
If connected - but no data          TCAS NO DATA

Air traffic within the optical range of the TCAD sensor (depends on Ryan TCAD mode) is displayed on the chart in relation to the terrain.

If the scale of the chart is too detailed to display all detected aircraft the symbols are displayed on the rim of the screen in correspondent position.

To see the position of the airtraffic on the chart choose → ZOOM → ZOOM-

### 16.1.3. Display of Avidyne Data on Multi Function Display (MFD Mode)



Notes on MFD mode (= dedicated mode):

- The sighting cylinder of the Ryan TCAD sensor changes according to the set mode (information displayed in top line).
- In exceptional cases, signals can be received from other aircraft located outside the sighting cylinder determined by the set mode, but these must be treated with caution.
- Moving Terrain's "critical cylinder" is fixed at 1 nm.
- Since several modules (TCAS, MT Satellite radar) can be depicted in MFD mode at the same time, the set range is valid for all. For example, the MFD can be set at 800 nm for assessing the current weather situation. However, as no TCAS data is available at long distances, there is little point in setting the MFD mode to such radii when only the TCAS is operating.



## Symbology

### A. Airtraffic with position data:

	or		above „critical zylinder“
	or		below „critical zylinder“
	or		within the „critical zylinder“ → dangerous because of flight characteristics, dangerously close
	or		within the „critical zylinder“ → distance not critical

- Glider symbol
- If the speed of another aircraft is too low to represent its speed, it will appear as a diamond marked with **F** instead of an airplane.
- Stated altitude is relative to your own aircraft (in 100 feet).
- Red arrow pointing upwards: Climbing faster than 500 fpm
- Red arrow pointing downwards: Descending faster than 500 fpm

### Speed vector:

The 15-second arrow on the nose of surrounding aircraft permits conclusions to be drawn on the aircraft category.

The white text next to the aircraft symbols informs about the vertical distance between your aircraft and the target. The given number 22 is to be read as 2200 ft (to give an example).

### B. Airtraffic without position data

The determined approach of aircraft with Mode S and Mode C transponders which do not provide information about their position, are represented as circular ring, as soon as the critical cylinder is achieved by the diameter of 1nm. The warning color of the ring follows the same logic as described above, the size of the ring shows the approach.

larger ring	more distance
smaller ring	closer




On the left half of the screen      TCAS FLARM  
If connected - but no data      TCAS NO DATA

Air traffic within the optical range of the FLARM sensor is displayed on the chart in relation to the terrain.

If the scale of the chart is too detailed to display all detected aircraft the symbols are displayed on the rim of the screen in correspondent position.

To see the position of the airtraffic on the chart choose → ZOOM → ZOOM-

### 16.2.3. PowerFLARM Data in MFD Mode



Notes on MFD mode (= dedicated mode):

- In exceptional cases, signals can be received from other aircraft located outside the sighting cylinder determined by the set mode, but these must be treated with caution.
- Moving Terrain's "critical cylinder" is fixed at 1 nm.

- Since several modules (TCAS, MT Satellite radar) can be depicted in MFD mode at the same time, the set range is valid for all. For example, the MFD can be set at 800 nm for assessing the current weather situation. However, as no TCAS data is available at long distances, there is little point in setting the MFD mode to such radii when only the TCAS is operating.

### 16.3. Symbology for traffic display of Avidyne + FLARM

See chapter 16.1. and 16.2 in combination.

Surrounding traffic is shown by flashing lights (more conspicuous, esp. on chart) and color coding:



blue - above the critical cylinder



brown - below the critical cylinder



red - within the critical cylinder, dangerously close



white - same altitude as the critical cylinder, but outside the danger zone

- Displayed as an airplane (SQUAWK shown in white box as of Avidyne)
- If the speed of another aircraft is too low to represent its speed, it will appear as a diamond instead of an airplane.
- Stated altitude is relative to your own aircraft (in 100 feet).
- Red arrow pointing upwards: Climbing faster than 500 fpm
- Red arrow pointing downwards: Descending faster than 500 fpm

Speed vector:

The 15-second arrow on the nose of surrounding aircraft permits conclusions to be drawn on the aircraft category.

The white text display in the aircraft symbols serves to indicate the difference in altitude between the aircraft and the traffic. The number shown (e.g., 22) is 2200 feet.

## 16.4. Symbols for data transmitted by ZAON XRX

Zaon specifies strong deviation for the transmitted bearing ( $\pm 45^\circ$ ). To take this into account the surrounding aircraft are presented as circular arcs with an angle of  $90^\circ$ .

The width of the circular arc is depending on the distance of the aircraft and the scale of the chart.

Zaon states the following tolerances:

Distance [nm]	Tolerance [nm]
> 6,0	$\pm 1 - 2$
3,0 - 5,9	$\pm 1$
2,0 - 2,9	$\pm 0,2 - 0,5$
1,0 - 1,9	$\pm < 0,2$
< 1,0	$\pm 0,1$

The color of the circular arc depends on the relative altitude and distance to the own aircraft.

Aircraft (position)	color
Above the critical cylinder	blue
Below the critical cylinder	brown
Within the critical cylinder, not within a direct danger zone	white
In the critical cylinder, DANGER due to little distance	rot

Turn on the traffic display  
→ AUX → TCAS → ON


Once it is started the setting will be saved and automatically turned on again at the next start of the system.

The traffic display will only work if the own aircraft is moving – due to relative display.

## 17. MT-Stormscope Interface\*

### 17.1. Switch on Stormscope display

→ AUX → STORM → ON



See here combination of radar, TCAS and stormscope data.  
Control panel for interface monitoring in the left part of the display.

### 17.2. Modes

- CELL display of cells
- STRIKE display of strikes
  
- CLR „Clear“ the screen to hide accumulated strikes or wind shear

### 17.3. Turn off Stormscope Mode

→ AUX → STORM → OFF

## 18. MT-Autopilot Interface: Guidance Output \*


Steering of an external autopilot via “Cross track error” signal.

Either with analog current +/- 10V  
 or via protocols: Aviation protocol COM3 / 9600 baud  
 or NMEA protocol COM3 / 4800 baud

Notes on configuration and connection of the interface can be found in the installation manual.

### 18.1. MT-Autopilot Guidance: Modi

- AUX
- AP interconnection to the autopilot
- APRTE autopilot follows the route
- APDCT autopilot follows the direct
- APHDG input of heading
- to correct an input type in further digits
- Confirm the input with Y
- N terminates and the AP status remains as before



- APOFF disconnect the autopilot

## 18.2. AP-Guidance: Status display

APRTE	AP RTE above route information (right lower part of the screen)
APDCT	AP DCT same place
APHDG	AP TRK and magnetic track (3 digits) (same place) – it is in fact a track, not a heading!

## 18.3 Logic for Autopilot Guidance

Once the autopilot is in the OFF state, a neutral signal (0 V) is emitted, which leads to a "wing level" status.

If the destination is reached, either at the end of the Direct vector or at the end of the last route segment the status is switched to AP OFF → "Wing level status."

The AP HDG status remains active, there is no terminating condition.

## 19. MT-Touch Screen \*

### 19.1. Move the Map with Fingertips to Desired Position

The touch function allows to work with the chart in MAP mode in 2D: base charts / single charts / overview chart.

Move the map with your finger to the desired position. The map follows your fingertip. When you lift your finger, the movement stops.

### 19.2. Selection of a Navigational Waypoint

Waypoints can be selected as well in FLT Mode as in MAP Mode in 2D (not on a single chart nor on the overview).

Tip on the waypoint on the map. This starts a search function in VFR IFR data base.

- Display of a box with
  - ICAO identification (e.g. EDMK).
  - distance,
  - elevation.
- Only 1 active waypoint at a time, a new selection replaces the previous
- The pointer in the data base is set to this waypoint in → NavWPT.  
This improves:
  - quick access to further info like frequencies, runway information and others
  - Set a DIRECT → DCT
  - Jump to this waypoint by → GOTO

## 20. PDF Viewer

Access, display and storage of PDF files.

- Access by → AUX → PDF
- List of all stored PDF files  
NOTE: PDFs files are **NOT displayed** if the
  - name of the PDF file contains spaces
  - name of the PDF file is encrypted
  - name of the PDF file is password protected
- ERASE (delete PDF file)
- 2 modes for usage:
  - OPEN (operation by the keyboard)
  - OPEN-M (operation with an external USB mouse)

Operation by keyboard

- R rotate
- Q quit the PDF viewer
- P go to previous page
- N go to next page
- D move down
- U move up
- 1-9 quick page forward in the (big) PDF file, page 10/20/30/40... /90
- function keys zoom in 400% to 12,5%
- I J L M Scrolling down, up, left and right (logic analogue to scrolling of base charts)

## 21. NVG Mode (Night Vision Goggles)

Dimming with the \* button on the left side.

Further dimming leads to NVG Mode. Last settings get saved.

## 22. MT-Mission Management System \*

### 22.1. Components for the Mission Management System

#### 22.1.1. Hardware

- MT-VisionAir X with SW version min. X.5.1 (OS13)
- Iridium Transceiver Antenna System (ITAS), Serial interface: 19200 bps
- Test cabling with power/serial M12/8pin connector
  
- MDR50 central connector with power, Fast Integral GPS and COM3 (pin assignment see Installation Manual)

ITAS must be connected to serial COM port 3.

#### 22.1.2. Contract for SBD (Short Burst Data)

Sign a contract for Iridium SBD. The IMEI no. of the ITAS module is part of the contract. (Mo ACK is not necessary).

#### 22.1.3. Contract with Rescue Track

Rescue Track needs to know the IP address for the hosting service.

### 22.2. Software

#### 22.2.1. Basic information

This module is an option and needs to be activated by MT.

#### 22.2.2. Settings on the Moving Terrain System

##### 22.2.2.1. Choice of ITAS Module for Communication

→ AUX → SETUP → DIAL-UP

Select IRIDIUM TRANSCEIVER ANTENNA SYSTEM (ITAS) by pressing UP / DOWN and confirm with USE.

The setting is saved.

### 22.2.2.2. Activation of data transfer to and from Rescue Track

The tracking system is always on and the position data is transmitted every 120 seconds to the server in Rescue Track.

The initialization of communication with Rescue Track has been made at the factory.

An interruption / disconnection can be done by turning off the ITAS module.

### 22.3. MMS via Rescue Track on the Bildschirm

→ AUX → MMS

<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p style="text-align: center;">Received messages (latest on top)</p> <p>2015-02-21 14:57 from: Sender  <span style="background-color: green; color: black;">[REDACTED]</span>  Text of received message 5 N42°12.1 E013°20.5</p> <p>2015-02-21 14:50 from: Sender  Text of received message 4</p> <p>2015-02-21 14:40 from: Sender  Text of received message 3</p> <p>2015-02-21 13:25 from: Sender  Text of received message 2</p> <p>2015-02-21 13:20 from: Sender  Text of received message 1</p> </div> <p style="text-align: center;">(in the background: normal map screen)</p>	<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">RescueTrack status</p> <p style="text-align: right;">Frei auf Funk &gt;</p> <p style="text-align: right;">Frei auf Wache &gt;</p> <p style="text-align: right;">Einsatz übernommen &gt;</p> <p style="text-align: right;">Am Einsatzort &gt;</p> <p style="text-align: right;">Sprechwunsch &gt;</p> <p style="text-align: right;"><span style="background-color: green; color: black;">Außer Dienst &gt;</span></p> <p style="text-align: right;">Patient übernommen &gt;</p> <p style="text-align: right;">Im Krankenhaus &gt;</p> <p style="text-align: right;">Ferry Flight &gt;</p> </div>										
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%;">GOTO</td> <td style="width: 10%;">DCT</td> <td style="width: 10%;">msgUP</td> <td style="width: 10%;">msgDN</td> <td style="width: 10%;"></td> <td style="width: 10%;">BACK</td> </tr> </table>		GOTO	DCT	msgUP	msgDN						BACK
GOTO	DCT	msgUP	msgDN						BACK		

### 22.3.1. Description of the Screen

Left half: incoming messages, the latest can be found at the top  
 Right half: standardized messages that are sent from the helicopter.

### 22.3.2. Incoming Messages

In the left half of the screen the last 5 incoming messages are displayed, the most recent at the top.

The latest message is automatically marked as active (highlighted green).

It is possible to choose one of the other messages

- msgUP up or
- msgDN down.

The selected message will be highlighted.

Once coordinates are included in the message, you get the choice of these options:

- GOTO → the map is centered according the given coordinates (ATTENTION: This ends the MMS menu!)
- DCT → to set a directs to the given coordinates  
The destination appears as RTDEST.

### 22.3.3. Recalling a message to the control center on the Moving Map

As soon as a new message arrives a hint is displayed in the main menu:

The hint flashes for better visibility.

Once the pilot has seen the message → AUX → MMS, this notice expires .



#### 22.3.4. Selection of the Standardized Status Messages Using the Keys 2- 0

- Press of the button → the message turns to **cyan**
- The sending is done automatically with the next position report
- Then the message remains **green** until another message is selected

Color coding of the current status:

- highlighted **cyan** = selected but not yet transmitted
- highlighted **green** = selected and transmitted

#### 22.3.5. BACK

- Back to Main Menu - Moving Map.

## 23. MT-Video Input Device (MT Camera) \*

### 23.1. Technical Description

A separate MT Video Input Device is part of the system.

Connection via USB, recommended to use the central connector.

Power supply of the MT Video Input Device via MT-VisionAir X (USB connection)

Possible signals:      Composite video (CVBS, RS 170)  
                                 PAL  
                                 NTSC

Input:                      1 x CVBS (composite video input, 75 Ohm) via BNC  
                                 Cinch connection via BNC-RCA adapter possible

Display:                    full screen in 4: 3 format with maximum resolution 1024 x 768 pixels.

### 23.2. Operation MT Video Input

Operation via hotkey C (C key on the keyboard).

- C      switches to Video In
- C      switches back to MFD screen with moving map functions

## 24. MT-VGA Output Device \*

A separate MT VGA Output device is part of the system.

Connection via USB, recommended to use the central connector.

Power supply of the MT Video Input Device via MT-VisionAir X (USB connection)

Output in VGA format.


## 25. Software Updates, OS Upgrade, Backup of User Data

### 25.1. Information about the system


→ AUX → SETUP → VERSION

the current version number is displayed

1 x press: SW version



2 x press: version of software  
OS (operating system) version  
Details for data storage  
Hardware ID + in brackets type of CPU



## 25.2. Software Update / Update of Charts and Data

### 25.2.1. Prerequisites

For the updates you need:

- Power supply
- USB stick = update stick

The USB stick contains the file firmware.img.

Either the data have been downloaded from our website and saved on the stick or we send the prepared USB stick..

### 25.2.2. Procedure

Make sure a uninterrupted power supply is provided.

- Power off MT-VisionAir
- Insert USB stick into the slot on the left bottom side of the MT unit with the logo showing upwards.
- Switch on MT-VisionAir X
- Update starts automatically
- Update was successful when the following message is shown: "Installation complete. Please remove update device and restart."
- Switch off MT-VisionAir X
- Remove the USB stick carefully and parallel to the slot.
- Switch on the unit again: starting the program might take some time. Once the keys are shining blue, background processes are running and MT program will be started soon.

For a long update process, the screen may turn dark (enter the sleeping mode). To get the message of the successful update, please press the \* button on the bottom left, so that the panel again „wakes up“. Wait for the message, do not pull out the stick before.



## 25.4. Backup of User Data

### 25.4.1. Prerequisites

For the backup you need:

- Power supply
- USB stick (FAT32 formatted)

### 25.4.2. Procedure

Make sure a uninterrupted power supply is provided.

Insert USB stick into an USB slot – you can also choose the remote USB Slot via central connector.

- Press → AUX → SYS → BACKUP
- This triggers a current backup of:
  - USER waypoints / routes / tracks
  - Logbook
  - Blitzplan FPL list and log in data
  - saved PDFs
  - current settings for display and system



- Wait till status changes to:



- Press → BACK
- Remove the USB stick

The data backup is now completed and can be transferred to  
other MT-VisionAir X  
Backup workstation

### 25.4.3. Error Message

If the USB stick cannot be detected the following error message shows up:



## 25.5 Restore of User Data

→ RESTORE restores the data from the backup USB stick,  
e.g. to synchronize several MT-VisionAir X systems

### 25.5.1. Procedure

Attention	All user data on the unit will be overwritten!
-----------	--

Make sure a uninterrupted power supply is provided.

- Insert USB stick (FAT32 formatted) with user data you want to restore into the USB slot.
- Press → AUX → SYS → RESTORE
- Data which are restored (= overwritten):
  - USER waypoints / routes / tracks
  - Logbook
  - Blitzplan FPL list and log in data
  - saved PDFs
  - current settings for display and system



## 26. MT-OPS Database Editor \*

### 26.1. Purpose

MTOPSDB is a simple tool to:

- a) Maintain the "OPS" waypoint database on a PC
- b) Load the "OPS" waypoints into MT VisionAir X units.

An "OPS" database contains waypoints that cannot be edited by the pilot but can only be used as they are - as opposed to "USER" waypoints.

The "OPS" waypoints can be accessed on the VisionAir X through: navWPT - DBASE - OPS (see the manual for details)

### 26.2. Prerequisites

- Windows OS (tested on Windows XP SP3, Windows 7 64-bit)
- USB port
- USB memory stick to transfer the data to the VisionAir X

### 26.3. Installation

- Extract the provided archive to a folder of choice ( e.g. c:\utility\mtopsdb ) maintaining the directory structure.

The program can be easily moved (even to another computer) as the software does not store any information outside its own folder.


- Optionally create a shortcut on the Windows start menu.

A quick way to do this: right-click on "mtopsdb.exe" and select "pin to start menu."

### 26.4. Usage

Start the program "mtopsdb.exe"

A window will appear:



### 26.4.1. Editing waypoint data

Click EDIT to open an editor (similar to Excel) where the waypoints can be managed:

	A	B	C	D	E	F	G	H	I	J	K	L	M
1	Name	ID	Hem	Lat	Lat	Lat	Hem	Lon	Lon	Lon	Comment	WptType	
2	ARBEDO	ARBED	N	46	12	880	E	009	02	530	LSZL VRP Arbedo	0	
3	MEZZOVICO	MEZZO	N	46	05	610	E	008	55	140	LSZL VRP Mezzovico	0	
4	GORDEVIO	GORDE	N	46	13	639	E	008	44	740	LSZL VRP Gordevio	0	
5	BRISSAGO	BRISSA	N	46	07	300	E	008	42	560	LSZL VRP Brissago	0	
6													
7													
8													
9													


Change, add or remove records as needed (see paragraph 5 for details)

When done, save the changes (File - Save) and leave the editor (File - Exit)

The initial window (EDIT - EXPORT - Exit) will appear again.

### 26.4.2. Exporting waypoints to the VisionAir X

- Plug an USB memory stick into the PC
- Preferably the USB stick should be empty or contain only a previous export of the OPS database, to avoid mixing extraneous files.
- If not already running, start “mtopsdb.exe”
- Click EXPORT, the software will show the following window:



- Click on the destination drive letter and press OK
- NOTE: do not select a specific folder, just the drive letter.

When the operation is complete the software will remind how to load the OPS waypoints into the VisionAir X:



- Click "Ok" to return to the main selection screen (EDIT - EXPORT – Exit)

### 26.4.3. Loading the OPS database into the VisionAir X

- Power up the VisionAir X
- Plug the USB memory stick (where the waypoint data has been exported) into any USB port of the unit
- Press: → AUX → SYS → RESTORE

The unit will list the data that can be read from the USB stick:



**IMPORTANT: ensure that the displayed list contains ONLY the OPS waypoint database.**

If other data is listed (e.g. User Waypoints from a previous backup) do not proceed unless you really want to reload all the listed databases and completely replace them on the unit. If unsure, erase everything from the USB stick and repeat the EXPORT operation.

To confirm loading the data on the unit press RESTORE again, otherwise press BACK.

Once the data has been loaded the VisionAir X will display a confirmation and will restart itself to update the database index:



The OPS database page should now display the loaded information, press navWPT - DBASE - OPS to verify:

NAV WPT PAGE (OPS)

**CURRENT WAYPOINT**

NAME:

IDENT:  TYPE:

LAT:  LON:

ELEV:

LSZL VRP Brissago

**SEARCH**

ARBED

ARBEDO

BRISSA

**BRISSAGO**

GORDE

GORDEVIO

MEZZO

MEZZOVICO

**MOVING TERRAIN**  
Air Navigation Systems AG

MODE **MAP300%**

**09:54:56**

**SATACQ**

**N 46 07.300'**

**E 008 42.560'**

ALT **4500 feet**

GS [kts] -- MT --

DCT ----

DME [nm] -- MC --

EET --:--:--

SINGLE CHART **LSGS11**

NXT WPT ----

DME [nm] -- MC --

EET --:--:--

DEST ----

DME [nm] --

EET --:--:--

DBASE
GOTO
DCT
DCTupd
DCTtmp
EDIT
CHAR
UP
DOWN
BACK

## 26.5. Details on editing the OPS waypoints

The MTOPSDB utility maintains the waypoint database in an Excel file (XLS format) named **"mtopsdb.xls"**

As such it can also be edited directly with Excel itself or a similar program (e.g. OpenOffice calc).

NOTE: Do not use the newer format "XLSX" introduced with Excel 2007, always save in "XLS" format.

The instructions below will describe the included editor but are mostly applicable to Excel, too.

### 26.5.1. Data format

The first row of the file must contain the column headers:

Name	ID	LatHem	LatDeg	LatMin	LatMMin	LonHem	LonDeg	LonMin	LonMMin	Comment	WptType
------	----	--------	--------	--------	---------	--------	--------	--------	---------	---------	---------

All other rows shall contain the waypoints - one per row - entered in the following format:

Column	Field	Example	Description
A	Name	ARBEDO	Long name of the waypoint (maximum 30 characters)
B	ID	ARBED	Short identification of the waypoint (maximum 7 characters)
C	LatHem	N	Latitude sign: N or S
D	LatDeg	46	Latitude degrees (00 .. 90)
E	LatMin	12	Latitude minutes (00 .. 60)
F	LatMMin	880	Latitude 1000ths of minute (000 .. 999)
G	LonHem	E	Longitude sign: E or W
H	LonDeg	009	Longitude degrees (000 .. 180)
I	LonMin	02	Longitude minutes (00 .. 59)
J	LonMMin	530	Longitude 1000ths of minute (000 .. 999)
K	Comment	LSZL VRP Arbedo	<i>Optional</i> remark (maximum 250 characters - must be a single line)
L	WptType	0	<i>Optional</i> - if present must be always 0 (zero) - <i>reserved for future expansion</i>

Notes about format:

- Changes of graphical formatting (font, color, column width) are safe and ignored by the conversion utility
- Empty rows are ignored
- Do not insert more than one line of text in a field (e.g. Comment)
- Spaces inserted in ID / NAME / Comment are handled properly
- The order of the rows is not relevant as the VisionAir X will reindex all waypoints by ID and name. However for easier maintenance on the PC they can be sorted - see below (5.3)

### 25.6.2. Deleting waypoints

Right-click on the row number to delete (on the left) and select "Delete":

Multiple waypoints can be deleted:

- Select several rows (click on the first row number and drag the mouse down)
- Right-click and select "Delete"



### 25.6.3. Inserting waypoints

Usually new waypoints should be added at the end of the list, but it is also possible to insert

a new row in the middle.

- Right-click on the row number that should be moved down to make room
- Select “Insert”


#### 25.6.4. Sorting waypoints

This is not a necessary operation, the VisionAir X always displays waypoints sorted by ID and Name automatically


However it can be easier to work on a sorted list on the PC.

To sort the records alphabetically:

- Click on the gray area on the upper left corner (on the left of “A” column and before row “1”) to select all the rows:



- From the menu bar select: Format - Data - Sort
- A dialog box will appear, select the sorting column(s) - usually “Name” or “ID” - and press “OK”:



#### 25.6.5. Searching for waypoints

- Press CTRL + F (or select Edit - Find) to search for a specific text in the whole file.

## 27. Autopilot Servo + Attitude + GPS Output \*

### 27.1. Purpose

This function provides an high-speed serial data stream containing:

- -Aircraft attitude
- GPS position
- Autopilot steering

### 27.2. Prerequisites

The Attitude+GPS Output will only work when:

- The unit is calibrated
- MT-EFIS\* is enabled
- The **Autopilot Servo + Attitude + GPS Output** function is enabled in mtpro.ini

### 27.3. Configuration

To enable the Attitude+GPS Output add the following to “mtpro.ini”:

```
[AttGpsOut]  
Port = 3
```

In the example the output is sent to COM3.

If “Port” is set to 0 (zero) the data output remains disabled.

### 27.4. Operation

The Attitude+GPS output is always active (data is always sent) when configured in mtpro.ini (unless “Port” is set to zero).

### 27.5. Protocol Specification

#### 27.5.1. Serial line configuration:

- Speed            115200
- Data bits        8

- Parity            N
- Stop bits        1

Flight Data packets are transmitted continuously at an average rate of 50 - 65 per second (depending on system load)

### 27.5.2 Packet format

Field name	C type	Length (bytes)	Description
sync1	unsigned int	4	Synchronization bytes Always 0xFFFFFFFF
sync2	unsigned int	4	Synchronization bytes Always 0xFFFFFFFF
pkt_type	unsigned char	1	Always 1 (new packet types may be added in future)
pkt_len	unsigned char	1	Number of remaining bytes in packet Always 50 (packet length - 10) for packet type 1
ts_msec	unsigned short int	2	Timestamp - milliseconds part of ts_sec
ts_sec	unsigned int	4	Unix Timestamp (seconds since 01/01/1970)
GPSLat	double	8	GPS latitude (degrees)
GPSLon	double	8	GPS longitude (degrees)
GPSAlt	float	4	GPS altitude (feet AMSL)
GPSTrack	float	4	GPS true track (degrees)
MagVar	float	4	Magnetic variation at GPSLat, GPSLon (from world magnetic model)
AHRSPitch	float	4	Pitch attitude (degrees, nose up is positive)
AHRSEBank	float	4	Bank attitude (degrees, bank right is positive)
AHRSTrack	float	4	Gyro-assisted GPS true track (Responds instantaneously to aircraft yaw movements)
Flags	unsigned int	4	Flag bits (value --> meaning): 1     -->   GPS fix is valid (otherwise ignore GPS fields) 2     -->   AHRS pitch/bank are valid 4     -->   AHRS track is valid 8     -->   AP Steering is valid

			16 --> AP Selected Altitude is valid
APSteering	float	4	Autopilot lateral steering Range: -100 .. +100 (positive = Aircraft turn to the right)  The value 100 represent full turn rate and may be interpreted as a standard rate turn (3 deg/s)
APElevator	float	4	Elevator Servo Position (Range: -100 .. +100 (positive = Aircraft moves nose-up)

Total packet size: 68 bytes

Note 1: Data types are in "x86" format (32-bit platform, "little-endian")

Note 2: GPS fields are only updated when new position data arrives (4 Hz for Fast Integral GPS).

Note 3: The AHRS "yaw" is slaved to the GPS true track (this explains the name "AHRSTrack")  
Magnetometer data is not available in current software release, and for the time being the VisionAir X does not know the aircraft heading but only GPS track.

Note 4: Timestamp is synchronized to GPS UTC time

Note 5: Peak transfer rate is: 68 (packet size) \* 65 (peak packets/sec) = 4420 bytes / sec  
(about 40% of bandwidth)

### 27.5.3. Declaration of packet structure (C language)

```
#pragma pack(push)
#pragma pack(1)
typedef struct
{
    unsigned int      sync1;          // Synchronization bytes: 0xFFFFFFFF
    unsigned int      sync2;          // Synchronization bytes: 0xFFFFFFFF
    unsigned char     pkt_type;       // Packet type, 1 for MT_FLIGHTDATA (for
protocol expansion)
    unsigned char     pkt_len;        // Remaining bytes in packet
[sizeof(MT_FLIGHTDATA) - 10]
    unsigned short int ts_msec;       // Milliseconds part of timestamp
    unsigned int      ts_sec;         // UNIX timestamp - seconds
    double            GPSLat;         // Degrees
    double            GPSLon;         // Degrees
    float             GPSAlt;         // AMSL altitude in feet
    float             GPSTrack;       // GPS true track (deg)
    float             MagVar;         // Magnetic variation (WMM) at GPSLat,
GPSLon
    float             AHRSPitch;      // Pitch (deg, nose up = positive)
    float             AHRSBank;       // Bank (deg, bank right = positive)
    float             AHRSTrack;      // Gyro-assisted GPS true track (deg)
    unsigned int      Flags;          // See below: MTFD_xxx constants
    float             APSteering;     // Autopilot roll steering
}
```

```
        float                APAltSel;    // AP selected altitude (feet)
    } MT_FLIGHTDATA;
#pragma pack(pop)


// Values for Flags bits
// Values for Flags bits
#define MTFD_GPSFIX          (1 << 0)    // GPS fix is valid (thus GpsXXX fields are
valid)
#define MTFD_AHRSATT        (1 << 1)    // AHRS attitude is valid
#define MTFD_AHRSTRK        (1 << 2)    // AHRS track is valid
#define MTFD_APSTEERING     (1 << 3)    // Autopilot steering is valid
#define MTFD_APALTSEL       (1 << 4)    // Autopilot selected altitude is valid
```

## 28. Mission Management Program MT Operations Center 1.0

### 28.1. Requirements

- **OS:** Windows XP (32 bit) or Windows 7 (32/64 bit)  
Note: other Windows versions may work but have not been tested
- **RAM:** minimum 1 GB (recommended at least 2 GB)
- **Disk space:** Software installation needs at least 60 MB (MT OPS Center) + 180 MB (Google Earth)
- **Dedicated e-mail account** for receiving Iridium SBD messages.
  - Supported mail protocols: POP3, IMAP (both unencrypted and SSL)
  - The mailbox must be linked to the Iridium SBD contract and should not contain any messages (other than the ones arriving from Iridium).
  - It is recommended to clean the dedicated mailbox from any "welcome" or similar messages that may have been generated when the account was created.
  - This release of the software does not send e-mail messages, thus an "SMTP" server is not required at this time (but may be in future versions)
- **Time:** it is recommended to maintain the computer's clock correctly synchronized (e.g. with an Internet time source). It is not necessary to set a specific timezone, but all times shown in MT OPS Center will be referred to UTC.

### 28.2. Diagram of functionality



### 28.3. General note for installation

It is recommended to install and run MT Operations Center 1.0 within an user account with "administrator" privileges on the machine.

This release works with Google Earth to display the position of the targets; the latest version is provided as a convenience, but it is exactly the same that can be downloaded for free (at the time of writing) from: <http://earth.google.com>.

## 28.4 Install MT OPS Center

- Start the installer named "**MTOpsCenter-setup.exe**"
- It is suggested to leave all the installation options active, including "Runtime library (Visual C++ 2008)", unless it is known for sure that this component is already present on the machine. (Press "**Next >**")
- The installation folder defaults to "C:\MTOPSCenter" (not the standard "Program Files") as the software does not support folder names containing spaces; moreover Windows 7 / Windows Vista security may prevent the program from running correctly if it is hosted under the "Program Files" system folder. (Press "**Install**")
- Once the file copy has completed press "**Close**" (the button will be disabled until the process has finished)

The installer adds a new program group named "MT OPS Center" in the Windows Start Menu.

### 28.4.1 Configuration

Before starting the software the first time it is recommended to configure it as follows:

Start --> Programs --> MT OPS Center --> Edit configuration

This will open the Windows Notepad to edit the configuration file ("`mtopscenter.ini`")  
Lines starting with ';' are comments; empty lines are ignored by the program.

There must be no spaces between the elements of each configuration line, and no spaces at the beginning or ending.

Parameter	Description
mailprotocol=	Protocol to use with the mail server, either <b>pop3</b> or <b>imap</b> Must be given by the mailbox provider  Example: mailprotocol=pop3
mailserver=	Name of the mail server Must be given by the mailbox provider  Example: mailserver=pop3.example.com
mailport=	Service port of the mail server Must be given by the mailbox provider  Example: mailport=110
mailoptions=	Additional options used to connect with the mail server

	<p>If the mailbox uses SSL (encryption) it is recommended to enter the following:</p> <p>mailoptions=/ssl/novalidate-cert</p> <p>Otherwise leave blank</p>
mailuid=	<p>Username used to access the mailbox <b>Must be given by the mailbox provider</b></p> <p>Example: mailuid=sbd</p>
mailpwd=	<p>Password used to access the mailbox <b>Must be given by the mailbox provider</b></p> <p>Example: mailpwd=secretpassword</p>
mailcheckintv=	<p>Interval between mailchecks (in seconds) If the default 15 seconds generates too much load on the mailserver it can be changed to 60 seconds or more.</p> <p>Example: mailcheckintv=15</p>
activetimeout=	<p>Timeout (minutes) to consider a target inactive If an "active" target does not send any information within the specified time from the last message it becomes "inactive"</p> <p>Example: activetimeout=4</p>

Save the file and close the text editor when done.

The next step is to set up the callsigns / tail numbers of the targets that will be tracked.

Start --> Programs --> MT OPS Center --> Edit fleet

The fleet configuration file will open in Windows Notepad (filename: "fleetdata.ini")  
This file should contain a description for each Iridium Satellite Phone that is tracked by the system.

The format is:

*imei\_code=tail\_number*

Example:

300115010909999=D-HXXX

Where "imei\_code" is the IMEI identifier of the Satphone, and "tail\_number" is the aircraft identification that will appear in the OPS Center.

Lines starting with ';' are comments, and empty lines are ignored.

There must be no spaces between the elements of each configuration line, and no spaces at the beginning or ending.


Save the file and close the text editor when done.

### 28.4.2 Usage

Launch the program from the Windows Start Menu: **Start --> Programs --> MT OPS Center --> MT OPS Center**

**NOTE: It is not possible to use two copies of MT OPS Center at the same time on the same mailbox.** The program will delete the Iridium messages as it processes them, so that if more than one copy is pulling the messages from the same account the tracking will be erratic. However it possible to run two copies on two different mailboxes if the Iridium SBD contract is set up to deliver messages to both of them simultaneously.

### 28.4.3 Main program window



The screenshot shows the MT OPS Center application window. It features a table at the top for tracking data, a message log below it, and a control panel at the bottom with buttons for 'Clear', 'Open Map', 'Start', 'Stop', and 'Quit'. A status indicator shows 'RUNNING'.

ID	Status	Lat/Lon	Alt	TrueTrk	Speed	LastReport
MT9555	---	N53 01.417' E006 29.690'	8000	230	100	2014-03-04 17:16:13

Message window content:

```

2014-03-05 16:52:10 Tracking started
2014-03-05 16:52:11 Checking for messages
2014-03-05 16:52:27 Checking for messages
2014-03-05 16:52:44 Checking for messages
  
```

Callouts in the image:

- Target list:** Points to the table above.
- Message window:** Points to the log area below the table.
- Action buttons:** Points to the 'Start' button.
- IDLE / RUNNING / STOPPED indicator:** Points to the 'RUNNING' status indicator.

All areas are initially blank and the program status is initially "IDLE": the user has to perform an action before anything will happen.

Press the "Start" button to begin processing of the tracking messages (program status shows "RUNNING")

The program will then check the mailbox periodically and update the "target list" as new data

becomes available.

The button "**Open map**" will start Google Earth and make it show the current position of the targets.

When Google Earth is started in this way it will continue to update the target positions according to the data that is processed by MT OPS Center.

The "**Stop**" button suspends the processing of the tracking messages: no position updates will be received and any Iridium messages from the satellite phones will remain queued in the mail server until the tracking is resumed.

Program status indicator shows "STOPPED".

The "**Clear**" button deletes all target data and removes all text from the message window. The targets will reappear only when they send the next position report.

The "**Quit**" button will close MT OPS Center. If Google Earth is still open it will not display updated information anymore, but will be up-to-date again if the OPS Center is launched and tracking is resumed.

#### Explanation of the columns shown in the target list

ID	Target identification The data packets coming from the Iridium devices are identified by the unique IMEI code of each satphone. If MT OPS Center knows about the sender (as configured in "fleetdata.ini") it will show the corresponding aircraft registration, otherwise it will display the full IMEI code of the transmitting equipment.
Status	Target active / inactive indicator If the target sent any message recently it will show "Active", otherwise "---" (dashes) The target activity timeout can be configured and defaults to 4 minutes
Lat/Lon	Last reported target position The format is in degrees and minutes with decimal part: Ndd mm.mmm Eddd mm.mmm
Alt	<b>Last reported target altitude</b> (feet AMSL)
TrueTrk	<b>Last reported true track</b> (degrees)
Speed	<b>Last reported ground speed</b> (kts)
LastReport	UTC time of last position report NOTE: This timestamp is provided by the Iridium network and represents the instant when the data packet was accepted by the satellite. It is typically 6 - 9 seconds later than the actual UTC time when the GPS position was acquired.

If the message window shows any error related to the mail server connection, the

configuration should be reviewed to ensure all the parameters are correct.  
It is recommended to "Quit" and restart the program after modifying the configuration file.

MT OPS Center will process all queued Iridium messages, so that it may take a few moments for it to catch up if the targets have been already sending tracking information for a long time.

Note that old queued messages will not show the corresponding target as "Active" unless they are recent enough.

## 28.5 Displaying target positions on Google Earth

### 28.5.1 Install Google Earth

Start the installer named "**GoogleEarthWin-7.12.2041.exe**" and follow the on-screen instructions.

Note that if a previous version of Google Earth is already installed on the machine this step is not strictly necessary: MT OPS Center should work with Google Earth versions as old as 5.x / 6.x

### 28.5.2 Settings in Google Earth


We recommend to take a few minutes now to start Google Earth the first time and change few settings which will make it more suitable to use with MT OPS Center:

- A window named "Start-up Tip" may open automatically. At its bottom deselect "Show tips at start-up" and click "Close".
- On the bottom of the Google Earth display there could be a "Tour Guide" strip containing photos. We suggest to disable it:
  - Open the "View" menu on the top of the Google Earth window
  - Deselect "Tour Guide"
- To increase performance we suggest to disable all the layers that are not of operational interest (e.g. Ocean, Weather, Places). These can be activated/deactivated on the bottom left section of the Google Earth window. It may be useful to leave "Borders and Labels" activated.
- It is suggested to delete the "Sightseeing Tour" layer that is listed on the left of the Google Earth window (under "Places"). To do so:
  - Right-click on "Sightseeing Tour"
  - Choose option "Delete"

- Confirm the deletion when asked
- Open the "Tools" menu and click on "Options"
  - In the "3D View" tab:
    - Set the preferred Latitude/Longitude format
    - Set the preferred units of measurement
  - In the "Navigation" tab:
    - Select "Do not automatically tilt while zooming"
- Click "OK" to save the settings

Now Google Earth should be closed (File --> Exit) to proceed with the installation.

Google Earth is launched by pressing "Open Map". Once the program starts the left area of the window should show the data that is being fed by MT OPS Center, under the "Temporary places" folder.



- The map can be "dragged" with the mouse to scroll the view (the arrow keys will also move the map)
- Rotating the mouse wheel will zoom in/out (also the keys "page up" and "page down" will work)
- By holding the mouse wheel pressed and moving the mouse, the view will tilt/rotate and show the 3rd dimension: targets are connected to the ground by a thin white line to highlight their height over the terrain.
- Pressing the "R" key should revert to a top-down view.

**NOTE 1:** In average it will take **between 6 and 20 seconds** for the Google Earth targets to be updated after the onboard equipment sends its position report. The onboard software attempts to report the aircraft position every 60 seconds.

**NOTE 2:** When closing Google Earth the program will ask whether the items under "Temporary places" should be saved into "My Places". It is recommended to press the button "**DISCARD**", otherwise on the next program run the target data will appear doubled. If this happens it is recommended to remove the item "MTMMS Targets" shown under "My Places" by right-clicking on it and choosing "Delete".

## 28.6 How to extract data for "displaying target positions on customer's GIS"

The latest target data can be read out of a file named "**targets.kml**", contained in the "MT OPS Center" installation directory.

This file is **rewritten every second**.

### Description of "targets.kml"

The file contains a **<Placemark> KML element for each target** that is being tracked by MT OPS Center.

Each **<Placemark>** is made up of these sub-elements:

- **<name>** contains the aircraft ID
- **<description>** contains the text that would be shown in Google Earth when the target is selected with the mouse
- **<styleUrl>** references the placemark symbol (icon) that is defined in the KML header and is always "#mtmms\_tgt"
- **<Point>** contains other sub-elements specifying the target position:
  - <extrude>1</extrude>** instructs Google Earth to draw a vertical line joint the target

with the ground

`<altitudeMode>absolute</altitudeMode>` indicates that the altitude is AMSL (0 = sea level)

`<coordinates>` contains the actual 3D coordinates of the target, separated by comma:

- Longitude (degrees)
- Latitude (degrees)
- Altitude (meters)

--- Sample dump of "targets.kml"

```
-----
<?xml version='1.0' encoding='ISO-8859-1'?>
<kml xmlns='http://earth.google.com/kml/2.0'>
<Document>
<Style id='mtmms_tgt'>
  <IconStyle>
    <color>ff00ffff</color>
    <Icon id='fdp_tgt_icon'>
      <href>http://maps.google.com/mapfiles/kml/shapes/open-
diamond.png</href>
    </Icon>
  </IconStyle>
  <LabelStyle>
    <color>ff80ffff</color>
  </LabelStyle>
  <ListStyle>
  </ListStyle>
</Style>

<Placemark>
  <name>MT9555</name>
  <description>Alt: 2539ft TTRK: 046 GS: 0kts<br/>Pos: N47 41.032' E010
20.933'<br/>Last report: 2014-03-06 17:05:08</description>
  <styleUrl>#mtmms_tgt</styleUrl>
  <Point>
    <extrude>1</extrude>
    <altitudeMode>absolute</altitudeMode>

<coordinates>10.348888397217,47.683860778809,773.88719882369</coordinates>
  </Point>
</Placemark>

</Document>
</kml>
```